

AD-A109 855

OCEAN DATA SYSTEMS INC ROCKVILLE MD  
RSVP UPGRADE AND MAINTENANCE.(U)  
DEC 81 J WEBSTER

F/6 20/1


UNCLASSIFIED


N00014-78-C-0818

NL

1 OF 2

AD-A  
109855






LEVEL

II

12



AD A109855

DTIC  
ELECTE  
S D  
JAN 21 1982  
F

DISTRIBUTION STATEMENT A

Approved for public release;  
Distribution Unlimited

DTIC FILE COPY



81 12 30 007

**odsi OCEAN DATA SYSTEMS, INC.**  
6000 EXECUTIVE BLVD., ROCKVILLE, MARYLAND 20852 • 301/881-3031

390329

Prepared for

Naval Ocean Research and Development Activity  
NSTL Station, Mississippi

Prepared Under  
Contract No. N00014-78-C-0818  
ODSI Project 1100

RSVP UPGRADE AND MAINTENANCE

Final Task Report

December 18, 1981

Accession For	
NTIS GRA&I	<input checked="" type="checkbox"/>
DTIC TAB	<input type="checkbox"/>
Unannounced	<input type="checkbox"/>
Justification	<i>Letter on file</i>
By	
Distribution/	
Availability Codes	
Dist	Avail and/or Special
<i>A</i>	

Prepared by

Jacqueline Webster  
Ocean Data Systems, Inc.  
Rockville, Maryland

This document has been approved  
for public release and  
distribution is unlimited

390329 x11

## FOREWORD

This document is a final task report for the RSVP Upgrade and Maintenance Task completed under Contract No. N00014-78-C-0818 for the Naval Ocean Research and Development Activity.

The RSVP system retrieves sound speed profiles from a modified NODC (National Oceanographic Data Center) data base, and determines representative profiles from the retrieved profiles. These representative profiles are then used for oceanographic analysis, including acoustic modeling.

Under this task, modifications were made to the computer programs in the RSVP system to make them easier to use. This task also included conversion to new computer facilities, data base maintenance, and documentation of an existing undocumented program.

This document is in three parts. The first part describes the improvements made to the RSVP retrieval program. The second part is the documentation of the RSVP plotting program. The third part is a description of the Cyber Control Language procedure that is used to run the RSVP system.

ODSI thanks Eigoro Hashimoto formerly of NORDA Code 320 and George Kerr of NORDA Code 321 for assistance with program specifications and for furnishing an environment conducive to completion of this task.



# OCEAN DATA SYSTEMS, INC.

## *Memorandum*

**To:** Dr. A. Anderson (Head - NORDA Code 320)  
**From:** Jacqueline Webster  
**Date:** 30 June 1980  
**Subject:** Upgrade of the RSVP System

The RSVP system retrieves sound profiles from a modified and reformatted NODC ocean station data base, and determines representative profiles from among those that are retrieved. The representatives are then used as input to acoustic modelling programs and for other oceanographic analysis. Under Contract No. N00014-78-C-0818, modifications were made to two of the programs in the system, RSVP and RSVPPLP. These modifications are summarized as follows:

### Changes to RSVP

1. Automation of the procedure whereby deep ocean sound speeds are retrieved. Deep ocean sound speeds are now automatically retrieved from a disk file rather than manual user selection from a punched card deck being required.
2. Extension of the summary of sound speed profiles by year from 1974 to 1999.
3. Addition of parity error checking on input of sound speed profiles.
4. Clarification of printer output.
5. Addition of a new format for disk output (used as input to program RSVPPLP).

### Changes to RSVPPLP

1. Increasing the flexibility of input specifications.
2. Addition of new features to the plotter output and making it more general.
3. Uncovering and correction of program errors.
4. Modification of the card output to standard FACT format.

Attached is documentation of the changes made to RSVP along with instructions for its use.

Documentation of RSVPPLP, prepared as part of the work performed under the previously mentioned contract, appears as a separate task report. RSVP is documented in:

AESD Sound-Speed Profile Retrieval System (RSVP), AESD Technical Note TN-74-03, October 1974, John J. Audet, Jr. and Gregory G. Vega.

cc: Eigo Hashimoto - NORDA Code 320  
Gilbert Jacobs

## **I. Changes to program RSVP**

### **I.1 Archival deep sound speeds**

The RSVP system uses archival deep sound speeds to determine critical depth where available data are not sufficiently deep, and to extend sound speed profiles when specified by the user. Previously, the RSVP user had to find the appropriate card containing the deep sound speeds from a card file, duplicate it and manually insert it in his input deck. The program has been modified so that the deep sound speeds can be specified in one of three ways:

1. The deep sound speeds can be specified on a punched card, as before.
2. The Marsden square number and quadrant are calculated by the program, and then used to search for matching deep sound speeds in a disk file.
3. The Marsden square number and quadrant can be specified by the user on punched card input. These are then used to obtain the matching deep sound speeds from the disk file.

The file containing the archival deep sound speeds consists of one record for each Marsden square quadrant. A description of the record follows:

Format	Character Positions	Variable Name	Description
F6.1	1-6*	BLT(I)	Maximum depth in meters for the I-th request area.
10F6.1	7-12,* 13-18, 19-24, . . . 61-66	(SVEXT(J,I), J=1,10)	Archival deep sound speeds in meters/sec for the I-th request area.
I3	69-71**	LMSQ	Marsden square number.
I1	73	LMSQ5	Quadrant number.

\* The value is placed anywhere in the positions specified with the decimal point expressed.

\*\*The value is right-justified in the positions specified with no decimal point.



## **1.2 Summary by Year**

The printed output from RSVP contains a count of the number of profiles in the area of interest for each 5-year period between 1900 and 1974. Added to this summary is a count of the profiles between 1975 and 1999. This was done in preparation for the updates that will be made to the sound speed data base.

## **1.3 Parity Errors**

In the previous version of RSVP, a hardware error encountered on reading the sound speeds was treated in the same way as an end-of-data. Thus a bad tape or disk could cause a user to assume that there was no data in the area, when there actually was data there. The current version of RSVP prints an error message and aborts the job.

## **1.4 Printer Output**

The headings in the printer output from RSVP were modified in order to make it easier to see what data were available in the data base, and what data were selected for analysis. A sample of the RSVP printer output is presented in Section II.4.

## **1.5 Disk Output**

The previous version of RSVP wrote all the printer output to a disk file for use by the next program in the system, RSVPPLP. This file used more disk space than necessary, causing a shortage of scarce disk storage when the RSVP system was used in preparing for an exercise. Therefore, the disk file output from RSVP was changed to a simpler more compact version.

The disk file consists of sets of sound speed profiles retrieved by RSVP as well as information used in retrieval of the profiles. Each set in this file is the output from one request (by ocean location and time of year) to program RSVP. There is a maximum of 16 sets per file.

Each set in the file consists of one record each of Types 1-4, followed by 35 records of Type 5 as described on the following pages. Record Types 1-4 are images of the original request specification input to program RSVP. Records of Type 5 contain the sound speed profiles that were retrieved by RSVP as a result of the request shown in Records 1-4.

A description of the five record types follows.

Record Type	Format	Character Positions	Variable Name	Description
1	6A10	1-60	(REQT(K,I), K=1,6)	Up to 60 alphanumeric characters for an identifying title and a date for the I-th request.
	I2	78-79**	I	Request number (1 - 16).
	I1	80	ISEQ	Record type number, equal to 1.
2	I2	1-2**	LL(1,I)	Degrees of lower latitude
	I2	4-5**	LL(2,I)	Minutes limit of search
	A1	7	LL(3,I)	Hemisphere area for I-th request.
	I2	10-11**	LL(4,I)	Degrees of upper latitude
	I2	13-14**	LL(5,I)	Minutes limit of search
	A1	16	LL(6,I)	Hemisphere area for I-th request
	I3	21-23**	LL(7,I)	Degrees of lower longitude
	I2	25-26**	LL(8,I)	Minutes limit of
	A1	28	LL(9,I)	Hemisphere search area for I-th request
	I3	31-33**	LL(10,I)	Degrees of upper longitude
	I2	35-36**	LL(11,I)	Minutes limit of
	A1	38	LL(12,I)	Hemisphere search area for I-th request.
	I3	50-52**	LMSQ	Marsden square number and quadrant number used by RSVP to look up the deep sound speeds in the archival file. If blank, deep sound speeds are specified by INDM below.
	I1	54	LQUAD	
	A1	55	INDM	If LMSQ and LQUAD above are specified, INDM is disregarded. If INDM is "M", the Marsden square and quadrant are calculated from latitude and longitude. If INDM is blank, deep sound speeds are entered from cards of type 4.
	I2	78-79**	I	Request number (1-16)
	I1	80	ISEQ	Record type number, equal to 2.

\*The value is placed anywhere in the positions specified with the decimal point expressed.

\*\*The value is right-justified in the positions specified with no decimal point.

Record Type	Format	Character Positions	Variable Name	Description
3	12(I2,IX)	1-2,** 4-5, 7-8, : 34-35	(ISN(M,I), M=1,12)	Month numbers (01-12) used in data search for I-th request.
	14	38-41**	IY(I)	Earliest year used in data search for I-th request.
	14	44-47**	MIND(I)	Minimum search depth in meters for I-th request.
	F4.0	50-53*	XSONIC(I)	Maximum search depth in meters of sonic layer for I-th request.
	F4.0	56-59*	SSXMIN(I)	Minimum search depth in meters of subsurface maximum for I-th request.
	I2	78-79**	I	Request number (1-16)
	I1	80	ISEQ	Record type number, equal to 3.
4	11F6.1	1-6*	BLT(I)	Maximum bottom depth in meters for the Marsden square quadrant.
		7-12,* 13-18, : 61-66	(SVEXT(J,I), J=1,10)	Archival deep sound speeds in meters/sec. used to extend profiles for the I-th request.
	13	69-71**	MSQ	Marsden square number for archival deep sound speeds.
	I1	73	MSQ5	Marsden square quadrant.
	I2	78-79**	I	Request number (1-16)
	I1	80	ISEQ	Record type number, equal to 4.

There is one record of each of Types 1-4, representing an RSVP request.

\*The value is placed anywhere in the positions specified with the decimal point expressed.

\*\*The value is right-justified in the positions specified with no decimal point.

Record Type	Format	Character Positions	Variable Name	Description
5	I2	9-10**	J	Sequence number (1-35) for sound speed profile point.
	I5	16-20**	LDEPTH(J)	Depth in meters at J-th sound speed profile point.
	F6.1	25-30*	RPROF(J)	Sound speed in meters/sec. at the J-th depth for the model (most typical) profile.
	F6.1	35-40*	SVLM(J,I)	Mean sound speed in meters/sec. at the J-th depth, for all profiles selected for the I-th request.
	F6.1	44-49*	SVMIN(J,I)	Minimum sound speed in meters/sec. at the J-th depth, for all profiles selected for the I-th request.
	F6.1	53-58*	SVMAX(J,I)	Maximum sound speed in meters/sec. at the J-th depth, for all profiles selected for the I-th request.
	F4.1	67-70*	SVLSD(J,I)	Standard deviation from the mean in meters/sec. at the J-th depth, for all profiles selected for the I-th request.
	I5	81-85**	CNT(J,I)	Number of observations at the J-th depth for all profiles selected for the I-th request.
	F6.1 F6.1 F6.1	95-100,* 104-109,* 113-118*	(SVLJ(J,K), K=1,3)	Sound speed in meters/sec. at the J-th depth for the 3 most representative profiles selected for the I-th request.
	I5	123-127**	LDEPTH(J)	Depth in meters at J-th sound speed profile point (repeat of second field above)

\*The value is placed anywhere in the positions specified with the decimal point expressed.

\*\*The value is right-justified in the positions specified with no decimal point.

## **II. RSVP User's Guide**

### **II.1 File Identification**

#### **II.1.1. Program Files**

The FORTRAN source of program RSVP is stored in the Program Library file PVEHRVPPL. The binary form of RSVP is stored as file PVEHRVPPLGO. The ID at Eglin is KM, and the ID at NSRDC is PVEH.

#### **II.1.2 Data Files**

The archival deep sound speeds are stored on a card-image disk file with the name PVEHDEEPSSARCHIVAL. The ID at Eglin is KM and the ID at NSRDC is PVEH.

At Eglin the sound speed data base is stored on magnetic tape (9-track, labelled, density 800 bpi). At NSRDC the data base is stored on removable disk packs. The data are grouped by geographical area. Following is a table showing file names, tape reel identifiers, and disk pack identifiers for each group of data.

STORAGE MEDIA FOR THE RSVP DATA BASE

MARSDEN SQUARES	AREA	EGLIN TAPES			NSRDC DISK PACKS	
		Original*	Backup	TAPE LABEL	FILE NAME	DISK PACK IDENTIFIERS
008 - 021 045 - 057 083 - 093 120 - 130	CENTRAL PACIFIC	0531	0462	PUJACENPAC	CENPAC	VSN=DV4726, SN=AE5D03, ID=PVGV
157 - 164 193 - 200 231 - 235 263 - 278 904 - 926	NORTHERN PACIFIC  ARCTIC OCEAN (PACIFIC)	0239	16386	PUJANORPAC	NORPAC	VSN=DV4726, SN=AE5D03, ID=PVGV
001 - 006 036 038 - 043 074 - 080 109 - 116 145 - 152	CENTRAL ATLANTIC OCEAN	3826	0774	PUJACENATL	CENATL	VSN=DV4726, SN=AE5D03, ID=PVGV
109 141 - 144 178 - 180	MEDITERRANEAN SEA	0572	4036	PUJAMEDSEA	MEDSEA	VSN=DV4726, SN=AE5D03, ID=PVGV
181 - 190 217 - 226 251 - 252 258 - 262	NORTH ATLANTIC OCEAN	0400	6135	PUJANORATL	NORATL	VSN=DV4726, SN=AE5D03, ID=PVGV

\* The external identifiers listed here are not the same as the internal labels (VSN) because these tapes were created at NSRDC. Therefore the LABEL card used to specify the tape should not contain a VSN.

STORAGE MEDIA FOR THE RSVP DATA BASE

MARSDEN SQUARES	AREA	EGLIN TAPES			NSRDC DISK PACKS	
		Original*	Backup	TAPE LABEL	FILE NAME	DISK PACK IDENTIFIERS
007 - 008 043 - 046 080 - 082 117 - 118	CARIBBEAN SEA	0306	4050	PUJACARIB	CARIB	VSN=DV4726, SN=AESD03, ID=PVGV
022 - 026 058 - 062 094 - 098 131 - 133 165 - 168 201 - 202	PHILIPPINE SEA  SEA OF JAPAN  SEA OF OKHOTSK	10996	13211	PUJAPHIOKJP	PHIOKJP	VSN=DV4726, SN=AESD03, ID=PVGV
027 - 032 063 - 069 099 - 105 324 - 331 360 - 368 396 - 404 432 - 441 447 - 468 504 - 513 540 - 549 576 - 585	INDIAN OCEAN	5150	0064	PUJAINDIAN	INDIAN	VSN=DV4727, SN=AESD04, ID=PVGV

\* The external identifiers listed here are not the same as the internal labels (VSN) because these tapes were created at NSRDC. Therefore the LABEL card used to specify the tape should not contain a VSN.

**I-4**

\* The external identifiers listed here are not the same as the internal labels (VSN) because these tapes were created at NSRDC. Therefore the LABEL card used to specify the tape should not contain a VSN.



## **II.2 RSVP Card Input**

A maximum of 16 ocean areas in which it is desired to find typical sound speed profiles can be specified in one RSVP run. For each ocean area specification, referred to as a request, there are up to 4 input cards. Duplicate input cards may be omitted when more than one request is being specified. That is, if an input card in one request is the same as the corresponding type of card for the previous request in the run, then that card may be omitted. A description of the 4 types of input cards to RSVP follows. Sample RSVP input cards appear following the card input description.

Card Type	Format	Character Positions	Variable Name	Description
1	6A10	1-60	(REQT(K,I), K=1,6)	Up to 60 alphanumeric characters for an identifying title and a date for the I-th request.
	I2	78-79**	I	Request number (1 - 16).
	I1	80	ISEQ	Card type number, equal to 1.
2	I2	1-2**	LL(1,I)	Degrees of lower latitude
	I2	4-5**	LL(2,I)	Minutes limit of search
	A1	7	LL(3,I)	Hemisphere area for I-th request.
	I2	10-11**	LL(4,I)	Degrees of upper latitude
	I2	13-14**	LL(5,I)	Minutes limit of search
	A1	16	LL(6,I)	Hemisphere area for I-th request
	I3	21-23**	LL(7,I)	Degrees of lower longitude
	I2	25-26**	LL(8,I)	Minutes limit of
	A1	28	LL(9,I)	Hemisphere search area for I-th request
	I3	31-33**	LL(10,I)	Degrees of upper longitude
	I2	35-36**	LL(11,I)	Minutes limit of
	A1	38	LL(12,I)	Hemisphere search area for I-th request.
	I3	50-52**	LMSQ	Marsden square number and quadrant number used by RSVP to look up the deep sound speeds in the archival file. If blank, deep sound speeds are specified by INDM below.
	I1	54	LQUAD	
	A1	55	INDM	If LMSQ and LQUAD above are specified, INDM is disregarded. If INDM is "M", the Marsden square and quadrant are calculated from latitude and longitude. If INDM is blank, deep sound speeds are entered from cards of type 4.
	I2	78-79**	I	Request number (1-16)
	I1	80	ISEQ	Card type number, equal to 2.

\*The value is placed anywhere in the positions specified with the decimal point expressed.

\*\*The value is right-justified in the positions specified with no decimal point.

Card Type	Format	Character Positions	Variable Name	Description
3	12(12,1X)	1-2,** 4-5, 7-8, : 34-35	(ISN(M,I), M=1,12)	Month numbers (01-12) used in data search for I-th request.
	I4	38-41**	IY(I)	Earliest year used in data search for I-th request.
	I4	44-47**	MIND(I)	Minimum search depth in meters for I-th request.
	F4.0	50-53*	XSONIC(I)	Maximum search depth in meters of sonic layer for I-th request.
	F4.0	56-59*	SSXMIN(I)	Minimum search depth in meters of subsurface maximum for I-th request.
	I2	78-79**	I	Request number (1-16)
	I1	80	ISEQ	Card type number, equal to 3.

Cards of type 4 are omitted when the archival deep sound speeds are to be obtained from the disk file, that is, when columns 50-55 on the type 2 card are blank.

4	11F6.1	1-6*	BLT(I)	Maximum bottom depth in meters for the Marsden square quadrant.
		7-12,* 13-18, : 61-66	(SVEXT(J,I), J=1,10)	Archival deep sound speeds in meters/sec. used to extend profiles for the I-th request.
	I3	69-71**	MSQ	Marsden square number for archival deep sound speeds.
	I1	73	MSQ5	Marsden square quadrant.
	I2	78-79**	I	Request number (1-16)
	I1	80	ISEQ	Card type number, equal to 4.

\*The value is placed anywhere in the positions specified with the decimal point expressed.

\*\*The value is right-justified in the positions specified with no decimal point.

[illegible]

SAMPLE RSVP CARD INPUT

## II.3 Sample jobs

### II.3.1 Sample Job Deck For Eglin

```

X107.T375.NT1.P4.                                HASHIMOTO      1608  9218VT16M021      26
REQUEST.TAPE60.*PF.SN=USET1.
ATTACH.TAPE4.PVEHDEEPSSARCHIVAL.ID=KM.SN=USET1.MH=1.
LAREL.TAPE1.L=PUJAMEI)SEA.R=D=HD.  PHYSICAL REEL NO. 0572
ATTACH.LGO.PVEHRSVPLGO.ID=KM.MH=1.SN=USET1.
LIMIT.2000.
COPYBF.TAPE1.DATIN.
RETURN.TAPE1.
REWIND.DATIN.
LOAD.LGO.
EXECUTE.RSVP.DATIN.
CATALOG.TAPE60.RSVPOUT.ID=KM.
000000000000000000000000 ← 7/8/9 card
AL                                     21/12/79
35 35 N 36 10 N    004 35 W 003 50 W                                     11
07 08                                     M                                     12
                                     1900  500  50  50                                     13
101                                     21/12/79                                     21
35 00 N 37 30 N    016 00 E 017 15 E                                     22
07                                     1900  500  50  50                                     23
4500.01524.51541.01554.21575.51593.01610.51628.01646.01664.01682.0 143 4 24
102                                     21/12/79                                     31
33 00 N 38 00 N    017 15 E 020 00 E                                     32
07 08                                     1940  500  50  50                                     33
LE1                                     21/12/79                                     41
31 30 N 34 30 N    026 30 E 029 00 E                                     42
LE2                                     142 2                                     51
33 30 N 35 00 N    029 00 E 032 00 E                                     52
000000000000000000000000 ← 6/7/8/9 card

```

### II.3.2 Sample Job Deck For Carderock

PUJAN,C47500J,T300,PJ,RP1.  
 CHARGE,PUJA,1W8GT18919.  
 ATTACH,LGO,PVEHHSVPLGO,ID=PVEH,MH=MORSE,MH=1.  
 ATTACH,TAPE4,PVEHOLEKPSARCHIVAL,ID=PVEH,MH=1.  
 REQUEST,TAPE60,PF.  
 PAUSE. JOB USES DISK PACK DV4726  
 MOUNT,VSN=DV4726,SN=AESU03.  
 ATTACH,TAPE1,MEDSEA,ID=PVUV,SN=AESD03,PW=MOOSE,MH=1.  
 LDSET,PHESETA=NGINF.  
 LGO.

CATALOG,TAPE60,RSVPOUT,ID=PVEH.

0000000000000000000000 ← 7/8/9 card

AL						21/12/79	11
35 35 N 36 10 N	004 35 W 003 50 W				M		12
07 08		1900	500	50	50		13
I01						21/12/79	21
35 00 N 37 30 N	016 00 F 017 15 E						22
07		1900	500	50	50		23
4500.01524.51541.01550.21575.51593.01610.51620.01646.01664.01682.0	143 4						24
I02						21/12/79	31
33 00 N 38 00 N	017 15 E 020 00 E						32
07 08		1940	500	50	50		33
LE1						21/12/79	41
31 30 N 34 30 N	026 30 E 029 00 E			142 2			42
LE2						21/12/79	51
33 30 N 35 00 N	029 00 E 032 00 E				M		52
0000000000000000000000							

← 6/7/8/9 card

## II.4 Sample RSVP Printer Output

AL	35	N	36	10	N	004	35	W	003	50	W	21/12/79	11
35	35	N	36	10	N	004	35	W	003	50	W	21/12/79	12
07	0A											50	50
101												21/12/79	13
35	00	N	37	30	N	016	00	E	017	15	E	50	50
07												21/12/79	14
4500.01524.51541.0155H.21575.51593.01610.51628.01646.01664.01682.0												21/12/79	15
102												50	50
33	00	N	38	00	N	017	15	E	020	00	E	50	50
07	0A											21/12/79	16
LE1												142	2
31	30	N	34	30	N	026	30	E	029	00	E	21/12/79	17
LE2												50	50
33	30	N	35	00	N	029	00	E	032	00	E	21/12/79	18
14												50	50
												21/12/79	19
												50	50
												21/12/79	20
												50	50
												21/12/79	21
												50	50
												21/12/79	22
												50	50
												21/12/79	23
												50	50
												21/12/79	24
												50	50
												21/12/79	25
												50	50
												21/12/79	26
												50	50
												21/12/79	27
												50	50
												21/12/79	28
												50	50
												21/12/79	29
												50	50
												21/12/79	30
												50	50
												21/12/79	31
												50	50
												21/12/79	32
												50	50
												21/12/79	33
												50	50
												21/12/79	34
												50	50
												21/12/79	35
												50	50
												21/12/79	36
												50	50
												21/12/79	37
												50	50
												21/12/79	38
												50	50
												21/12/79	39
												50	50
												21/12/79	40
												50	50
												21/12/79	41
												50	50
												21/12/79	42
												50	50
												21/12/79	43
												50	50
												21/12/79	44
												50	50
												21/12/79	45
												50	50
												21/12/79	46
												50	50
												21/12/79	47
												50	50
												21/12/79	48
												50	50
												21/12/79	49
												50	50
												21/12/79	50
												50	50
												21/12/79	51
												50	50
												21/12/79	52

SAMPLE RSVP OUTPUT (Page 1 of 6)

RSVP DATA CARDS										21/12/79								
AL	35	N	36	10	N	004	35	W	003	50	W	1900	500	50	M	50		11
07	08																	12
																		13
101	35	00	N	37	30	N	016	00	E	017	15	E	1900	500	50	50		21
07																		22
4500.01524.51541.01550.21575.51593.01610.51628.01646.01664.01682.0																		23
21/12/79																		24
102	33	00	N	38	00	N	017	15	E	020	00	E	1940	500	50	50		31
07																		32
4500.01524.51541.01550.21575.51593.01610.51628.01646.01664.01682.0																		33
21/12/79																		34
LE1	31	30	N	34	30	N	026	30	E	029	00	E	1940	500	50	50		41
07																		42
																		43
LE2	33	30	N	35	00	N	029	00	E	032	00	E	1940	500	50	50		51
07																		52
																		53

THE MARSDEM SQUARES TO CONSIDER FOR PROFILE RETRIEVAL ARE 109 THROUGH 143  
 END RETRIEVAL AT MARSDEM SQUARE 144



21/12/79

AL

SEQ	MSQ	S	IO	LAT	LONG	DATE	STA	OWS	BOT	STA	D	SFC	SS	LD	SMA	D	AXIS	D	AXIS	SS	CU	CD	SS
1	109	3	53	35 40 N	3 56 W	8/14/57	14	14	0	526	1533.4	0.0	0.0	0.0	0.0	0.0	215.0	1508.6	1704.1	1533.4			1533.4
2	109	3	54	35 56 N	4 30 W	7/22/62	17	18	0	836	1532.8	0.0	0.0	0.0	0.0	0.0	213.0	1509.0	1668.6	1532.8			1532.8
3	109	3	54	35 51 N	4 13 W	7/24/53	14	10	0	500	1533.8	10.0	0.0	0.0	0.0	0.0	200.0	1508.9	1727.8	1533.8			1533.8
4	109	3	54	35 52 N	4 15 W	8/ 3/62	18	15	0	985	1535.2	0.0	0.0	0.0	0.0	0.0	246.0	1509.7	1810.7	1535.2			1535.2
5	109	3	54	35 40 N	4 15 W	8/ 3/62	18	16	0	940	1536.6	0.0	0.0	0.0	0.0	0.0	235.0	1509.4	1893.5	1536.6			1536.6
6	109	3	54	35 45 N	4 30 W	8/ 3/62	16	20	0	788	1538.1	0.0	0.0	0.0	0.0	0.0	249.0	1509.3	1982.2	1538.1			1538.1
7	109	3	54	35 58 N	4 11 W	8/ 1/58	22	13	1362	1319	1534.0	1.0	0.0	0.0	0.0	0.0	190.0	1508.1	1739.6	1534.0			1534.0
8	109	3	54	35 58 N	4 2 W	8/14/57	16	15	0	765	1532.2	0.0	0.0	0.0	0.0	0.0	430.0	1512.4	1633.1	1532.2			1532.2
9	109	3	64	36 0 N	4 34 W	7/20/62	15	19	0	615	1531.8	0.0	0.0	0.0	0.0	0.0	167.5	1508.2	1609.5	1531.8			1531.8
10	109	3	64	36 0 N	4 32 W	7/23/54	16	11	0	700	1530.5	0.0	0.0	0.0	0.0	0.0	200.0	1508.6	1532.5	1530.5			1530.5
11	109	3	64	36 6 N	4 31 W	8/14/62	17	17	0	851	1537.4	0.0	0.0	0.0	0.0	0.0	182.0	1508.2	1940.8	1537.4			1537.4

SAMPLE RSV P OUTPUT (Page 3 of 6)

# AECD ENVIRONMENTAL INFORMATION SYSTEM

21/12/79

AL

LATITUDE AND LONGITUDE BOUNDARIES 35 35 N 36 10 N 4 35 W 3 50 W

MONTHS INCLUDED IN DATA RETRIEVAL 7 R

EARLIEST YEAR OF DATA RETRIEVAL 1900

MINIMUM DEPTH FOR DATA RETRIEVAL 500 METERS

MINIMUM SEARCH DEPTH FOR SONIC LAYER 50 M MINIMUM SEARCH DEPTH FOR SUBSURFACE MAXIMA 50 M

MAXIMUM SEARCH DEPTH FOR SONIC PROFILE (M/S) EXTENDED TO 10,000 METERS

BOTTOM (MAX) ARCHIVAL DEEP SOUND SPEED PROFILE (M/S) EXTENDED TO 10,000 METERS  
 3000.0 1000 2000 3000 4000 5000 6000 7000 8000 9000 10000  
 1521.5 1538.4 1555.5 1573.6 1592.0 1610.0 1628.0 1646.0 1664.0 1682.0

• • • • •

## DISTRIBUTION OF ALL OCEAN STATIONS FOR THE AREA REQUESTED

TOTAL NUMBER OF STATIONS IN THE AREA 43 (INCLUDES SHALLOW STATIONS AND PROFILES WITH MISSING DATA)

MONTH SUMMARY				YEAR SUMMARY				DEPTH SUMMARY										
JAN	APR	3	JUL	9	OCT	1	1900-04	0	35-39	0	70-74	0	0-500	15	2001-2500	0	4001-4500	0
FEB	MAY	2	AUG	10	NOV	0	05-09	1	40-44	0	75-79	0	501-1000	21	2501-3000	0	5001-5500	0
MAR	JUN	7	SEP	0	DEC	0	10-14	1	45-49	11	80-84	0	1001-1500	7	3001-3500	0	5501-6000	0
							15-19	0	50-54	5	85-89	0	1501-2000	0	3501-4000	0	6000-9999	0
							20-24	2	55-59	8	90-94	0						
							25-29	1	60-64	14	95-99	0						
							30-34	0	65-69	0								

NUMBER OF STATIONS USED FOR ANALYSIS AND MODEL PROFILE SELECTION 11

SAMPLE RSPV OUTPUT (Page 4 of 6)

# STATISTICAL INFORMATION AND PROFILE COLLECTION

(STATISTICS ARE COMPUTED FROM ALL PROFILES FOR THE AREA, YEARS, AND MONTHS REQUESTED, INCLUDING SHALLOW STATIONS AND PROFILES WITH MISSING DATA)

AL

21/12/79

DEPTH (M)	MODEL PROFILE	SOUND SPEED SUMMARY (M/S)	STANDARD DEVIATION (M/S)	NUMBER OF OBSERVATIONS	REPRESENTATIVE PROFILES	DEPTH (M)
0	1532.8	MEAN 1534.5	2.5	16	(1) 1533.4 (2) 1532.8 (3) 1535.2	0
10	1528.3	1530.5	3.1	16	1532.2	10
20	1524.6	1523.1	2.9	16	1532.2	20
30	1522.4	1521.3	2.4	18	1524.7	30
40	1519.2	1518.0	2.2	18	1519.2	40
50	1515.6	1515.0	2.6	18	1515.8	50
60	1513.3	1511.4	2.4	18	1512.3	60
70	1512.2	1509.4	2.0	17	1511.1	70
80	1511.1	1508.7	1.6	17	1510.1	80
90	1509.3	1508.3	1.1	17	1508.7	90
100	1509.1	1509.5	.7	16	1509.3	100
110	1510.1	1509.6	.5	16	1510.0	110
120	1511.9	1510.3	.3	14	1511.6	120
130	1513.4	1511.9	1.9	14	1513.7	130
140	1514.9	1506.1	.2	11	1513.4	140
150	1516.3	1514.7	.1	11	1514.9	150
160	1517.6	1516.5	.2	10	1516.3	160
170	1519.7	1517.9	.1	7	1517.6	170
180	1521.3	1519.7	.1	4	1519.8	180
190	1522.9	1521.2	.1	2	1521.3	190
200	1524.6	1522.9	0.0	1	1522.9	200
210	1526.3	1524.6	0.0	1	1524.6	210
220		1526.3	0.0	1	1526.3	220
230						230
240						240
250						250
260						260
270						270
280						280
290						290
300						300
310						310
320						320
330						330
340						340
350						350

PROFILE	ID	MSU	MS05	MS01	LATITUDE	LONGITUDE	DATE	TIME	DEPTH (M)	BOTTOM (M)
(1)	1	109	3	53	35 40 N	3 56 W	8/14/57	14	528	
(2)	1	104	3	54	35 56 N	4 30 W	7/22/62	0	A36	
(3)	1	4	109	3	35 52 N	4 15 W	8/ 3/62	0	945	

SAMPLE RSVP OUTPUT (Page 5 of 6)

SOUND SPEED PROFILE CHARACTERISTICS  
(COMPUTED USING THE 11 PROFILES SELECTED FOR ANALYSIS)

21/12/79

AL

MEAN SOUND SPEED AT THE SURFACE 1534.2 M/S 2.3 M/S (ONE STANDARD DEVIATION)

LAYER DEPTH SUMMARY

PERCENTAGE OCCURRENCE 10 PERCENT  
(PERCENTAGE OF TOTAL STATIONS INDICATING A SONIC LAYER DEPTH)

MEAN DEPTH 6 METERS 5 METERS (SD)  
(ZERO DEPTH SONIC LAYER NOT INCLUDED IN MEAN DEPTH CALCULATION)

MEAN SOUND SPEED AT THE LAYER 1533.9 M/S .1 M/S (SD)

MEAN GRADIENT 0.000 M/S/M 0.000 M/S/M (SD) RANGE OF GRADIENTS 0.000 TO 0.000 M/S/M  
(SURFACE SOUND SPEED TO SONIC LAYER DEPTH)

BELOW LAYER GRADIENT -.336 M/S/M .120 M/S/M (SD)  
(GRADIENT FROM SONIC LAYER TO AT LEAST 30 METERS BELOW SONIC LAYER OR  
IF NO SONIC LAYER, GRADIENT IS THAT COMPUTED FROM THE SURFACE TO 30 METERS)

SUBSURFACE SOUND SPEED MAXIMA (SOUND SPEED FLUCTUATIONS GREATER THAN 0.2 M/S LOCATED ABOVE THE AXIS)

PERCENTAGE OCCURRENCE 0 PERCENT

DEEP SOUND CHANNEL AXIS (DEEPEST SOUND SPEED MINIMUM)

MEAN DEPTH 230 M 6M M (SD)

MEAN SOUND SPEED 1509.1 M/S 1.1 M/S (SD)

CRITICAL DEPTH (CONJUGATE DEPTH)

MEAN DEPTH 1749 M 136 M (SD) 11 PROFILES EXTRAPOLATED TO OBTAIN CRITICAL DEPTH VALUES  
(CRITICAL DEPTH IS THAT DEPTH OCCURRING BELOW THE DEEP SOUND CHANNEL AXIS  
WITH A SOUND SPEED EQUAL TO THE NEAR-SURFACE SOUND SPEED MAXIMUM)

RANGE OF MEASURED BOTTOM DEPTHS IN AREA OF INTEREST 202 TO 1460 METERS  
(MEASURED BOTTOM DEPTHS OBTAINED FROM THE OCEAN STATION FILES ARE CONSIDERED APPROXIMATE AND SHOULD  
BE USED ONLY TO INDICATE PROBABLE BOTTOM LIMITING ON DEPTH EXCESS CONDITIONS IN THE AREA)

SAMPLE RSVP OUTPUT (Page 6 of 6)

**odsi OCEAN DATA SYSTEMS, INC.**  
6000 EXECUTIVE BLVD., ROCKVILLE, MARYLAND 20852 • 301/881-3031

Submitted To:

Office of Naval Research  
Washington, D.C.

RSVP PLOT/PUNCH (RSVPPLP) PROGRAM

Technical Task Report

June 30, 1980

Prepared under  
Contract N00014-78-C-0818

Prepared by:

J. Webster  
Ocean Data Systems, Inc.  
Rockville, Maryland 20852

## FOREWORD

This document is a task report prepared under Contract No. N00014-78-C-0818 for the Office of Naval Research, Washington, D.C., in support of the Naval Ocean Research and Development Activity (NORDA) - Code 320, Bay St. Louis, Mississippi. The report describes the work performed in fulfilling part of the contract, and serves as documentation for a computer program to be used in plotting or punching representative sound speed profiles from an archival file of ocean station data.

Ocean Data Systems, Inc. is indebted to Eigoro Hashimoto, NORDA Code 320, for assistance with program specifications and for furnishing an environment conducive to completion of this task.

### ABSTRACT

This report contains a description of program RSVPLP, part of the RSV (Retrieve Sound Velocity Profile) system. Program RSVPLP allows plotting and punching of the sound speed profiles that are retrieved by the system. The report includes instructions for use of RSVPLP and sample run decks illustrating execution of the program at the computer facilities at the David Taylor Naval Ship Research and Development Center (DTNSRDC), Carderock, Maryland, and at Eglin Air Force Base, Florida.

## TABLE OF CONTENTS

<u>SECTION</u>		<u>PAGE</u>
	FOREWORD . . . . .	i
	ABSTRACT . . . . .	ii
	TABLE OF CONTENTS . . . . .	iii
	LIST OF FIGURES . . . . .	iv
I.	INTRODUCTION . . . . .	I-1
II.	INPUT. . . . .	II-1
	1. Mass Storage Input . . . . .	II-1
	2. Card Input . . . . .	II-6
III.	OUTPUT. . . . .	III-1
	1. Printed Output . . . . .	III-1
	1. Standard Output . . . . .	III-1
	2. Error Messages . . . . .	III-1
	2. Plotted Output . . . . .	III-5
	3. Card Output . . . . .	III-7
IV.	PROGRAM DESCRIPTION . . . . .	IV-1
	1. Main Program . . . . .	IV-1
	2. Subroutine ABRT . . . . .	IV-9
	3. Subroutine ANNOT . . . . .	IV-11
	4. Subroutine AXES . . . . .	IV-14
	5. Subroutine FRITZ . . . . .	IV-17
	6. Subroutine LEGEND . . . . .	IV-24
	7. Subroutine PAGE . . . . .	IV-27
	8. Subroutine PLDASH . . . . .	IV-29
	9. Subroutine PLDOT . . . . .	IV-31
	10. Subroutine PLOTIT . . . . .	IV-33
	11. Subroutine PLPROF . . . . .	IV-38
	12. Subroutine PNCH . . . . .	IV-43
	13. Subroutine SCALDS . . . . .	IV-45
V.	CROSS REFERENCE CHARTS . . . . .	V-1
	1. Subroutine Cross Reference . . . . .	V-1
	2. COMMON Cross Reference. . . . .	V-2
VI.	USER'S GUIDE . . . . .	VI-1
	1. File Identification. . . . .	VI-1
	2. Sample Jobs . . . . .	VI-2



# LIST OF FIGURES

<u>FIGURE</u>		<u>PAGE</u>
I-1	Job Flow for the RSVP System . . . . .	I-2
II-1	Sample Card Input . . . . .	II-9
III-1	Sample Printer Output . . . . .	III-2
III-2	Sample Plotter Output . . . . .	III-6
III-3	Sample Card Output . . . . .	III-9


## **I. INTRODUCTION**

The RSVP system was developed by the Acoustic Environmental Support Detachment (AESD) of the Office of Naval Research. It retrieves, along with other relevant data for acoustic modeling, representative or model sound speed profiles for a given ocean location and time of year. The data base used by the system is a subset of ocean station data from the National Oceanographic Data Center (NODC). For further information about the retrieval process, see the following report:

"AESD Sound-Speed Profile Retrieval System (RSVP)," by John J. Audet, Jr., and Gregory G. Vega; AESD Technical Note TN-74-03, October 1974.

The report herein presented describes RSVPPLP, a program for plotting, modifying, filtering or punching the RSVP retrieved sound speed profiles. RSVPPLP is a modification of program RSVPPREP, which was part of the RSVP system developed by Vega and Audet. Figure I-1 on the following page shows how RSVPPLP fits into the RSVP system.

Section II of this document describes the input required by program RSVPPLP. Section III describes the output produced by the program. Section IV contains individual descriptions of each module of RSVPPLP, along with a description of COMMON storage. Section V has cross reference charts for COMMON storage and for the program modules. Section VI contains information needed for running the program - file names and sample jobs.



**FIGURE I-1: JOB FLOW FOR THE RSVP SYSTEM**

## **II. INPUT**

### **II.1 Mass Storage Input**

Mass storage input for RSVPPLP consists of a file containing sets of sound speed profiles that were output from program RSVP along with information used in retrieval of the profiles. Each set in this file is the output from one request (by ocean location and time of year) to program RSVP. There is a maximum of 16 sets per file.

Each set in the file consists of one record each of Types 1-4, followed by 35 records of Type 5 as described on the following pages.

Record Types 1-4 are images of the original request specification input to program RSVP. None of the information on Record Types 1-4, except the title from Record Type 1 and the archival deep sound speeds from Record Type 4, is used by program RSVPPLP. Records of Type 5 contain the sound speed profiles that were retrieved by RSVP as a result of the request shown in Records 1-4.

A description of the five record types follows.

Record Type	Format	Character Positions	Variable Name	Description
1	6A10	1-60	(REQT(K,I), K=1,6)	Up to 60 alphanumeric characters for an identifying title and a date for the I-th request.
	I2	78-79**	I	Request number (1 - 16).
	I1	80	ISEQ	Record type number, equal to 1.
2	I2	1-2**	LL(1,I)	Degrees of lower latitude
	I2	4-5**	LL(2,I)	Minutes limit of search
	A1	7	LL(3,I)	Hemisphere area for I-th request.
	I2	10-11**	LL(4,I)	Degrees of upper latitude
	I2	13-14**	LL(5,I)	Minutes limit of search
	A1	16	LL(6,I)	Hemisphere area for I-th request.
	I3	21-23**	LL(7,I)	Degrees of lower longitude
	I2	25-26**	LL(8,I)	Minutes limit of
	A1	28	LL(9,I)	Hemisphere search area for I-th request.
	I3	31-33**	LL(10,I)	Degrees of upper longitude
	I2	35-36**	LL(11,I)	Minutes limit of
	A1	38	LL(12,I)	Hemisphere search area for I-th request.
	I3	50-52**	LMSQ	Marsden square number and quadrant number used by RSVP to look up the deep sound speeds in the archival file. If blank, deep sound speeds are specified by INDM below.
	I1	54	LQUAD	
	A1	55	INDM	If LMSQ and LQUAD above are specified, INDM is disregarded. If INDM is "M", the Marsden square and quadrant are calculated from latitude and longitude. If INDM is blank, deep sound speeds are entered from cards of type 4.
	I2	78-79**	I	Request number (1-16)
	I1	80	ISEQ	Record type number, equal to 2.

\*The value is placed anywhere in the positions specified with the decimal point expressed.

\*\*The value is right-justified in the positions specified with no decimal point.

Record Type	Format	Character Positions	Variable Name	Description
3	12(I2,I X)	1-2,** 4-5, 7-8, : 34-35	(ISN(M,I), M=1,12)	Month numbers (01-12) used in data search for I-th request.
	I4	38-41**	IY(I)	Earliest year used in data search for I-th request.
	I4	44-47**	MIND(I)	Minimum search depth in meters for I-th request.
	F4.0	50-53*	XSONIC(I)	Maximum search depth in meters of sonic layer for I-th request.
	F4.0	56-59*	SSXMIN(I)	Minimum search depth in meters of subsurface maximum for I-th request.
	I2	78-79**	I	Request number (1-16)
	I1	80	ISEQ	Record type number, equal to 3.
4	11F6.1	1-6*  7-12,* 13-18, : 61-66	BLT(I)  (SVEXT(J,I), J=1,10)	Maximum bottom depth in meters for the Marsden square quadrant.  Archival deep sound speeds in meters/sec. used to extend profiles for the I-th request.
	I3	69-71**	MSQ	Marsden square number for archival deep sound speeds.
	I1	73	MSQ5	Marsden square quadrant.
	I2	78-79**	I	Request number (1-16)
	I1	80	ISEQ	Record type number, equal to 4.

There is one record of each of Types 1-4, representing an RSVP request.

\*The value is placed anywhere in the positions specified with the decimal point expressed.

\*\*The value is right-justified in the positions specified with no decimal point.

Record Type	Format	Character Positions	Variable Name	Description
5	I2	9-10**	J	Sequence number (1-35) for sound speed profile point.
	I5	16-20**	LDEPTH(J)	Depth in meters at J-th sound speed profile point.
	F6.1	25-30*	RPROF(J)	Sound speed in meters/sec. at the J-th depth for the model (most typical) profile.
	F6.1	35-40*	SVLM(J,I)	Mean sound speed in meters/sec. at the J-th depth, for all profiles selected for the I-th request.
	F6.1	44-49*	SVMIN(J,I)	Minimum sound speed in meters/sec. at the J-th depth, for all profiles selected for the I-th request.
	F6.1	53-58*	SVMAX(J,I)	Maximum sound speed in meters/sec. at the J-th depth, for all profiles selected for the I-th request.
	F4.1	67-70*	SVLSD(J,I)	Standard deviation from the mean in meters/sec. at the J-th depth, for all profiles selected for the I-th request.
	I5	81-85**	CNT(J,I)	Number of observations at the J-th depth for all profiles selected for the I-th request.
	F6.1 F6.1 F6.1	95-100,* 104-109,* 113-118*	(SVLJ(J,K), K=1,3)	Sound speed in meters/sec. at the J-th depth for the 3 most representative profiles selected for the I-th request.
	I5	123-127**	LDEPTH(J)	Depth in meters at J-th sound speed profile point (repeat of second field above)

\*The value is placed anywhere in the positions specified with the decimal point expressed.

\*\*The value is right-justified in the positions specified with no decimal point.

There are 35 records of Type 5, one for each profile depth level.

Sets of records of Types 1-4 followed by 35 records of Type 5 are repeated for each RSVP request, up to a maximum of 16 requests.



## II.2 Card Input

Card input to RSVPPLP consists of one card for each set of sound speed profiles to be plotted and/or punched from an RSVP output file. The card specifies:

1. The sequence number of the RSVP request to be processed from the RSVP output file. This corresponds to the number punched in columns 78-79 in the original request specification input to the RSVP retrieval.

2. The indices of the profiles to be selected from those produced by the RSVP request. Except for the numbers 5 and 6, the indices refer to the column numbers on the printed output of the sound speed profiles from program RSVP. The index numbers and the corresponding profile selected are shown below.

<u>Profile Index No.</u>	<u>Profile Selected</u>
1	Model
2	Mean
3	Minimum
4	Maximum
5	Mean minus standard deviation
6	Mean plus standard deviation
7	Representative No. 1
8	Representative No. 2
9	Representative No. 3

3. The processing options. There are three of these:

<u>Code</u>	<u>Meaning</u>
T	Extend the specified profile with mean values first and then, if necessary, with archival deep sound speeds (from Record Type 4 described in Section II.1) to a specified level.
M	Extend with mean values only.
F	Filter the data by eliminating points from the profile, but still leaving a good representation of the curve. See the description of subroutine FRITZ in Section IV.5 for more details on the filtering option.

Note that T and M are mutually exclusive.

4. Editing. Up to three points may be replaced in or added to the selected profiles.

## 5. Output options.

<u>Code</u>	<u>Meaning</u>
P	Plot the selected profiles. Only one graph is generated per input card; all the profiles selected are plotted on the same graph.
N	Same as P, except that every 5th point on the profiles is annotated with its profile index number.
C	Punch the selected profiles.

Each input card is a self-contained entity and specifies the RSVP request number, the index of one or more profiles to be processed, and for each index specified, either zero, one or two of the processing options. After all the indices and their corresponding processing options appears, the output options are specified. This is followed by parameters used in the editing and filtering, and a title used to identify the plotter/punch output.

The format of the card is given below. Sample card input appears on succeeding pages.

Format	Columns	Variable Name	Description
I2	1-2**	JSET	The RSVP request number of the set of profiles to be processed. Input cards must be in increasing order by this number.
8A1	3-10	(LSEL(I), I=1,8)	Processing parameters specified as an index (1-9) for each profile to be processed, followed by the processing options (T, M, F) for that profile, terminating with the output options (P, C) for the set of profiles. See the explanation above for more details. See the following pages for sample input.
I2 F7.0 I2 F7.0 I2 F7.0	11-12,** 14-20,* 21-22,** 24-30,* 31-32,** 34-40*	(MD(I), SM(I), I=1,3)	Data to be used in editing sound speed profiles. Expressed as pairs of sequence number within profile and replacement sound speed in meters/sec. The specified editing is done to all profiles selected in columns 3-10 above. A maximum of 3 points can be replaced or added. MD(I) cannot be larger than 35. If no editing is desired, leave these fields blank.

\*The value may appear anywhere in the indicated columns with the decimal point punched.

\*\*The value must be right-justified in the indicated columns with no decimal point.

Format	Columns	Variable Name	Description
I2	41-42**	LC	Number of points to be selected from each of the specified profiles when the selected profile is filtered. Maximum is 35. Default is 15.
F3.1	43-45*	TL	Tolerance in meters per second used for filtering option (F). Maximum is 3.75. Default is 1.5. See description of Subroutine FRITZ in Section IV.5 for a detailed explanation of this parameter.
3A10	46-75	NOTE2	Up to 30 alphanumeric characters used as annotation on the plot and as an identifier for the punched output.
I1	76	NEXT	Index number of the deep level to which profiles are to be extended, using archival deep sound speeds from the Type 4 record described in Section II.1. Next is used when processing option T is chosen in columns 3-10. Deep level 1 is 1000 meters, level 2 is 2000 meters, and so on to level 9 at 9000 meters. If NEXT is blank or 0, then the deep level is set to 10000 meters.
I3	78-80	DMAX	Maximum depth, in hundreds of meters, for plotting sound speed profiles. If DMAX is blank or 0, then a default of 6000 meters is assumed. If DMAX is set to a negative number, then the maximum depth for plotting is computed by the program.

This parameter card is repeated for each set of data to be selected, up to a maximum of 16 cards. Cards must be in increasing order by the request number in columns 1 and 2.

\*The value may appear anywhere in the indicated columns with the decimal point punched.

\*\*The value must be right-justified in the indicated columns with no decimal point.



### **III. OUTPUT**

#### **III.1 Printer Output**

##### **III.1.1 Standard Output**

A listing of each profile selected is printed along with sequence numbers for each point in the profile. A heading at the top of each profile indicates the original RSVP request number and the processing done on the profile. Points on the profiles which have been filtered out are printed as zero.

See the following page for a sample printout.

##### **III.1.2 Error Messages**

An error in entering the RSVP request number on an input card to RSVPPLP produces the following message:

```
*****BAD REQUEST NO. j
      input card
      ABOVE INPUT CARD REJECTED
```

where j is the request number from the input card. The program continues with the next input card.

Printed by: Main program

Solution: Check columns 1-2 to be sure that the request number is between 1 and 16 inclusive.

---

An error in the sequence of the input cards for RSVPPLP produces the following message:

```
*****REQUEST NO. j OUT OF ORDER
      input card
      ABOVE INPUT CARD REJECTED
```

where j is the request number from the input card. The program continues with the next input card.

Printed by: Main program

Solution: Check columns 1 and 2 of each input to make sure that they are in order by request number.

---

	1 MODEL	1 CALMT	1 FILT	2 MEAN	2 MEAN-SD	2 MEAN+SD	J MODEL	3 MIN	3 MAX	4 MEPI	4 EATM	4 FILT
1	1532.8	1532.8	1532.8	1539.5	1534.2	1540.8	1542.1	1534.7	1545.5	1543.3	1543.3	1543.3
2	1528.3	1528.3	1528.3	1537.1	1531.6	1540.6	1540.6	1521.5	1545.3	1541.6	1541.6	1541.6
3	1524.6	1524.6	1524.6	1529.6	1526.2	1533.0	1536.3	1517.1	1545.9	1526.5	1526.5	1526.5
4	1522.4	1522.4	1522.4	1521.9	1519.3	1524.5	1524.3	1514.4	1547.4	1522.1	1522.1	1522.1
5	1519.2	1519.2	1519.2	1516.8	1515.9	1517.7	1514.6	1512.9	1521.5	1519.8	1519.8	1519.8
6	1515.6	1515.6	1515.6	1513.4	1512.2	1514.6	1514.0	1511.3	1519.9	1518.2	1518.2	1518.2
7	1513.3	1513.3	1513.3	1512.7	1512.3	1513.2	1513.4	1509.4	1518.9	1517.6	1517.6	1517.6
8	1512.2	1512.2	1512.2	1512.6	1512.3	1512.9	1513.3	1510.1	1519.0	1517.8	1517.8	1517.8
9	1511.1	1511.1	1511.1	1512.7	1512.5	1512.9	1513.4	1511.3	1519.1	1517.9	1517.9	1517.9
10	1509.3	1509.3	1509.3	1513.3	1513.0	1513.6	1513.7	1511.9	1519.2	1518.0	1518.0	1518.0
11	1509.1	1509.1	1509.1	1513.4	1513.3	1514.3	1514.5	1512.9	1518.7	1517.8	1517.8	1517.8
12	1510.1	1510.1	1510.1	1514.3	1513.0	1515.0	1515.2	1513.1	1518.6	1517.8	1517.8	1517.8
13	1511.9	1511.9	1511.9	1515.4	1514.7	1516.1	1516.2	1514.9	1519.6	1517.7	1517.7	1517.7
14	1513.4	1513.4	1513.4	1516.7	1516.0	1517.4	1517.1	1516.2	1520.7	1517.8	1517.8	1517.8
15	1514.9	1514.9	1514.9	1518.1	1517.6	1518.6	1518.5	1517.7	1521.5	1518.8	1518.8	1518.8
16	1516.3	1516.3	1516.3	1519.6	1519.1	1520.1	1519.9	1519.3	1522.5	1519.9	1519.9	1519.9
17	1517.6	1517.6	1517.6	1521.2	1520.8	1521.6	1521.4	1520.8	1523.5	1521.1	1521.1	1521.1
18	1519.7	1519.7	1519.7	1522.5	1522.2	1522.8	1522.8	1522.3	1524.6	1522.6	1522.6	1522.6
19	1521.3	1521.3	1521.3	1524.1	1523.8	1524.4	1524.4	1523.7	1525.8	1524.2	1524.2	1524.2
20	1522.9	1522.9	1522.9	1525.7	1525.6	1525.8	1526.0	1525.7	1526.3	1525.8	1525.8	1525.8
21	1524.6	1524.6	1524.6	1527.3	1527.1	1527.5	1527.6	1527.3	1527.9	1527.4	1527.4	1527.4
22	1526.3	1526.3	1526.3	1529.0	1528.8	1529.2	1529.2	1528.9	1529.6	1529.1	1529.1	1529.1
23	0.0	0.0	0.0	1530.7	1530.5	1530.9	1530.8	1530.6	1531.3	1530.8	1530.8	1530.8
24	0.0	0.0	0.0	1532.3	1532.1	1532.5	1532.5	1532.0	1534.1	1532.5	1532.5	1532.5
25	0.0	0.0	0.0	1536.6	1536.5	1536.7	1536.7	1536.1	1537.3	1536.7	1536.7	1536.7
26	0.0	1534.4	0.0	1541.0	1541.0	1541.0	1541.0	1540.3	1541.3	1541.0	1541.0	1541.0
27	0.0	0.0	0.0	1549.5	1549.5	1549.5	1549.5	1548.9	1549.9	0.0	1549.5	1549.5
28	0.0	1555.5	1555.5	1558.0	1558.0	1558.0	1557.8	1557.8	1557.9	0.0	1558.1	1558.1
29	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	1575.5	1575.5
30	0.0	1573.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	1593.0	1593.0
31	0.0	1542.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	1610.5	1610.5
32	0.0	1610.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	1628.0	1628.0
33	0.0	1628.0	1628.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	1646.0	1646.0
34	0.0	1646.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	1664.0	1664.0
35	0.0	1682.0	1682.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	1682.0	1682.0

FIGURE III-1: SAMPLE PRINTER OUTPUT

An error in entering the options on an input card to RSVPPLP produces the following message:

\*\*\*\*\*BAD OPTION o  
input card  
ABOVE INPUT CARD REJECTED

where o is the option from the input card. The program continues with the next input card.

Printed by: Main program

Solution: Check columns 3-10 to make sure that the options are M, T, F, C, P, or N.

---

An error in the RSVP data file produces the following message:

\*\*\*\*\*BAD RSVP DATA  
RSVP record

The program aborts after printing the message and the bad record.

Printed by: Main program

Solution: Check that the preceding run of RSVP was executed properly, and that the correct file name was used for the RSVPPLP run.

---

When the end of data is reached on the RSVP data file before all the input cards to RSVPPLP have been processed, the following message is printed:

\*\*\*\*\*NO MORE DATA ON RSVP FILE  
ALL INPUT CARDS WERE NOT PROCESSED

The program terminates normally.

Printed by: Main program

Solution: Check the input cards for a request number that does not exist in the preceding RSVP run.

---

If any of the sound speeds to be plotted are outside the range for plotting, the following error message is printed:

\*\*\*\*\*SOUND SPEED POINT i, d, s,  
FOR PROFILE INDEX j OUTSIDE PLOT BOUNDS

where i is the sequence number of the point within the profile,  
d is the depth of the point in meters,  
s is the sound speed of the point in meters/second,  
j is the profile index number.

Printed by: Subroutine PLPROF

Solution: Check output of RSVP program for points with speeds less than 1200 or greater than 1800 meters/sec.



### **III.2 Plotted Output**

Plotted output is optional; it occurs only if the code P or the code N is punched in the appropriate place in columns 3-10 of the input parameter card. Only one graph can be generated by each input card. All the profiles selected on the input card are plotted on the same graph.

See the descriptions of the plotting subroutines PLOTIT, ANNOT, AXES, LEGEND, and PLPROF for details about the plotted output.

See the following page for a sample of plotted output.


# PROFILE ANNOTATION

1 - MODEL  
 2 - MEAN  
 3 - MINIMUM  
 4 - MAXIMUM  
 5 - STANDARD DEVIATION  
 6 - MEAN + STANDARD DEVIATION  
 7 - REPRESENTATIVE 1  
 8 - REPRESENTATIVE 2  
 9 - REPRESENTATIVE 3

# PROCESSING OPTIONS

M - EXTENDED WITH MEAN + ARCHIVAL  
 T - EXTENDED WITH MEAN  
 F - FILTERED  
 E - EDITED

III-6



MODEL

1 - TF

FIGURE III-2. SAMPLE PROFILE OUTPUT

### III.3 Card Output

Punched card output is optional. Card images are written on logical unit 3 if the code C is punched in the appropriate place in columns 3-10 of the input parameter card.

For each profile, a set of card images is output consisting of a header card (Type 1), a card containing the number of points in the profile (Type 2) followed by cards containing the profile expressed as depth, sound speed pairs, four pairs per card (Type 3).

The format of the output cards is described below. A listing of a sample punched card output is shown on a succeeding page.

Card Type	Format	Columns	Variable Name	Description
1	4A10	1-40	(ID(I,ISET), I=1,4)	First 40 characters of the identifying title from the original RSVP request sequence number ISET.
	3A10	41-70	(NOTE2(I), I=1,3)	Alphanumeric identification from columns 46-75 of the input parameter card.
	A10	71-80	LHS(K)	Alphanumeric description of the type (e.g., mean, model, etc.) for the Kth profile selected.
2	I5	1-5	L**	Number of points in the profile. Maximum is 35.

There is one Type 1 card followed by one Type 2 card for each profile punched.

---

\*\*Value is right-justified in specified columns with no decimal point punched.

Card Type	Format	Columns	Variable Name	Description
3	8F10.3	1-10,* 11-20,* . . 61-70,* 71-80*	(DT(I),ST(I), I=1,L)	The sound speed profile, expressed as pairs of (depth, sound speed) in (meters, meters/sec).

Cards of Type 3 are repeated, with up to 4 profile points per card, until all points in the profile have been specified, up to a limit of 35 points.

---

\*The value is positioned anywhere in the columns specified with the decimal point punched.

MODEL						FILE			
AL	14	0.00	1517.40	10.00	1524.30	20.00	1524.60	30.00	1527.40
		75.00	1515.60	100.00	1513.30	200.00	1504.30	250.00	1509.10
		500.00	1517.40	800.00	1517.60	1000.00	1521.30	3000.00	1555.50
		7000.00	1624.00	10000.00	1682.00	MEAN			
		MEAN +- S. D.							
101	2A	0.00	1539.50	10.00	1537.10	20.00	1529.60	30.00	1521.90
		50.00	1516.80	75.00	1513.40	100.00	1512.70	125.00	1517.60
		150.00	1512.70	200.00	1513.30	250.00	1513.80	300.00	1514.30
		400.00	1515.40	500.00	1516.70	600.00	1518.10	700.00	1519.60
		800.00	1521.20	900.00	1522.50	1000.00	1524.10	1100.00	1525.70
		1200.00	1527.30	1300.00	1529.00	1400.00	1530.70	1500.00	1532.30
		1750.00	1536.60	2000.00	1541.00	2500.00	1549.50	3000.00	1558.00
		MEAN +- S. D.							
101	2A	0.00	1538.20	10.00	1533.60	20.00	1526.20	30.00	1519.30
		50.00	1515.90	75.00	1512.20	100.00	1512.20	125.00	1512.30
		150.00	1512.50	200.00	1513.00	250.00	1513.30	300.00	1513.60
		400.00	1514.70	500.00	1516.00	600.00	1517.60	700.00	1519.10
		800.00	1520.80	900.00	1522.20	1000.00	1523.80	1100.00	1525.60
		1200.00	1527.10	1300.00	1528.80	1400.00	1530.50	1500.00	1532.10
		1750.00	1536.50	2000.00	1541.00	2500.00	1549.50	3000.00	1558.00
		MEAN +- S. D.							
101	2A	0.00	1540.80	10.00	1540.60	20.00	1533.00	30.00	1524.50
		50.00	1517.70	75.00	1514.60	100.00	1513.20	125.00	1512.90
		150.00	1512.90	200.00	1513.60	250.00	1514.30	300.00	1515.00
		400.00	1516.10	500.00	1517.40	600.00	1518.60	700.00	1520.10
		800.00	1521.60	900.00	1522.80	1000.00	1524.40	1100.00	1525.80
		1200.00	1527.50	1300.00	1529.20	1400.00	1530.90	1500.00	1532.50
		1750.00	1536.70	2000.00	1541.00	2500.00	1549.50	3000.00	1558.00
		MODEL MIN MAX							
102	2A	0.00	1542.10	10.00	1540.60	20.00	1536.30	30.00	1528.30
		50.00	1518.60	75.00	1514.00	100.00	1513.40	125.00	1513.30
		150.00	1513.40	200.00	1513.70	250.00	1514.50	300.00	1515.20
		400.00	1516.20	500.00	1517.10	600.00	1518.50	700.00	1519.90
		800.00	1521.40	900.00	1522.80	1000.00	1524.40	1100.00	1526.00
		1200.00	1527.60	1300.00	1529.20	1400.00	1530.80	1500.00	1532.50
		1750.00	1536.70	2000.00	1541.00	2500.00	1549.50	3000.00	1557.80
		MIN							
102	2A	0.00	1534.70	10.00	1521.50	20.00	1517.10	30.00	1514.80
		50.00	1512.90	75.00	1511.30	100.00	1509.40	125.00	1510.10
		150.00	1511.30	200.00	1511.90	250.00	1512.90	300.00	1513.10
		400.00	1514.90	500.00	1516.20	600.00	1517.70	700.00	1519.30
		800.00	1520.80	900.00	1522.30	1000.00	1523.70	1100.00	1525.70
		1200.00	1527.30	1300.00	1528.90	1400.00	1530.60	1500.00	1532.00
		1750.00	1536.10	2000.00	1540.30	2500.00	1548.90	3000.00	1557.80
		MAX							
102	2A	0.00	1545.50	10.00	1545.30	20.00	1545.90	30.00	1537.40
		50.00	1523.50	75.00	1519.90	100.00	1518.40	125.00	1519.00
		150.00	1519.10	200.00	1519.20	250.00	1518.70	300.00	1518.60
		400.00	1519.60	500.00	1520.70	600.00	1521.50	700.00	1522.50
		800.00	1523.50	900.00	1524.60	1000.00	1525.80	1100.00	1526.30
		1200.00	1527.90	1300.00	1529.60	1400.00	1531.30	1500.00	1534.10
		1750.00	1537.30	2000.00	1541.30	2500.00	1549.90	3000.00	1557.90

FIGURE III-3: SAMPLE CARD OUTPUT

#### IV. PROGRAM DESCRIPTION

##### IV.1 Main Program

**Function:** To extend, filter, edit, plot and/or punch sound speed profiles that have been previously retrieved (using program RSVP) from the NODC/LRAPP Geofile.

**COMMON Storage:** COMMON storage is not used in the RSVPPLP main program. It is used only in subroutine PLOTIT for communication with subsidiary plotting routines.


**Description:** Program RSVPPLP reads an input parameter card. It checks the card for validity, and then examines the options specified in the card for selection, processing, and output of sound speed profiles.

The specified profiles are read from the data file output by program RSVP, and moved to a processing array where they are edited or extended (in the main program) or filtered (by subroutine FRITZ). The profiles, both before and after each stage of processing, are stored in an array for later printing using subroutine PAGE.

If one of the output options on the input card is plotting, the processed profiles are plotted using subroutine PLOTIT and its subsidiary plotting subroutines ANNOT, AXES, LEGEND, PLPROF, and SCALDS. If one of the output options is punched cards, the card images of the processed profiles are written to a disk file using subroutine PNCH.


Succeeding input cards are read and the RSVP profile data specified by them is read and processed until there are no more input cards to be read.

See the next page for a diagram of the main program flow.



RSVPPLP


Page 1 of 7



RSVPPLP


Page 2 of 7






RSVPPLP

Page 3 of 7




RSVPPLP

Page 4 of 7




RSVPPLP

Page 5 of 7



RSVPPLP

Page 6 of 7



RSVPPLP

#### IV.2 Subroutine ABRT (NAME)

**Function:** To abort the job when an error has occurred, after printing a message giving the name of the program module that was in control when the error was detected.

**Where Called:** Main program

**Parameter Input:** NAME - Alphanumeric name of the program calling ABRT.

**COMMON Input:** None

**Card Input:** None

**File Input:** None

**Parameter Output:** None


**COMMON Output:** None

**Printer Output:** The following message is printed:  
\*\*\*\*\*RSVPPLP ABORTED IN name.

**File Output:** None

**Description:** ABRT prints the error message and then calls a dummy subroutine ABORT that, on the CDC 6000 series computers, causes the run to terminate abnormally.

**Error Messages:** None



ABRT

Page 1 of 1

#### IV.3 Subroutine ANNOT (ICAP1, ICAP2, LABEL, ICN)

**Function:** To put an annotation at the bottom of a graph of RSVP sound speed profiles, identifying the profiles and explaining the processing that has been done on each of the profiles prior to plotting.

**Where Called:** Subroutine PLOTIT.

**Parameter Input:** ICAP1 - A 40-character alphanumeric identifier for the original RSVP run that selected the profiles according to location and month of the year.

ICAP2 - A 30-character alphanumeric identifier from the RSVPPLP card input.

LABEL - An array containing up to 5 descriptors for each profile plotted. Word 1 contains the profile index number (1-9) used to annotate each individual profile. Words 2-5 contain the codes (M,T,F,E) used to indicate the processing that has been done on the profile. See Section IV.6 (Subroutine LEGEND) for an explanation of the profile index numbers and the processing codes.

ICN - The number of sound speed profiles.

**COMMON Input:** None

**Card Input:** None

**File Input:** None

**Parameter Output:** None

**COMMON Output:** None

**Printer Output:** None

**Plotter Output:** At the bottom of the graph of a set of profiles, the alphanumeric identifiers in arrays ICAP1 and ICAP2 are plotted. Under these are plotted identifying labels for each of the profiles on the graph. They are of the form:


$$I - P_1 \dots P_n$$

where I is the profile index number used to annotate the profile, and the P's indicate the processing performed on the profile.



**Description:** The subroutine plots the first caption, followed by the second caption, and then plots a label for each profile on the graph.

**Error  
Messages:** None



ANNOT

Page 1 of 1

#### IV.4 Subroutine AXES

**Function:** To draw and annotate depth and sound speed axes for RSVP plots.

**Where Called:** Subroutine PLOTIT.

**Parameter Input:** None

**COMMON Input:** /DPLOT/ ISCALD - Index into the depth scaling arrays used for the current graph.

LENY - Number of divisions on the depth axis.

YINC - Length in inches of a division on the depth axis.

DPMAX - Maximum depth in meters on the depth axis.

YFAC - Multiplicative factor to convert axis tic annotation to meters.

/SPLOT/ ISCAL5 - Index into the sound speed scaling arrays used for the current graph.

LENX - Number of divisions on the sound speed axis.

XINC - Length in inches of a division on the sound speed axis.

SSINC - Length in meters/sec. represented by a division on the sound speed axis.

SSMIN - Minimum sound speed in meters/sec. on the sound speed axis.

**Card Input:** None

**File Input:** None

**Parameter Output:** None

**COMMON Output:** None


**Printer Output:** None

**Plotter Output:** A depth axis is drawn with an origin at the top left corner of the graph, with depth increasing downward. This axis is repeated on the right side of the graph. Sound speed axes are drawn on the top and bottom of the graph. The axes are labelled.

**File Output:** None

**Description:** Using the index ISCALD, the appropriate depth scaling parameters are picked out of the scaling tables, and the depth axis is drawn and numbered on the left side of the graph. Using the index ISCALS, the appropriate sound speed scaling parameters are picked out of the scaling tables, and the sound speed axis is drawn and numbered along the top of the graph. Then a repeat of the depth axis is drawn on the right side, and a repeat of the sound speed axis is drawn on the bottom. Finally, titles are drawn on the left hand and top axes.

**Error Messages:** None



#### IV.5 Subroutine FRITZ (D, S, N, NSEL, SR, NR, ER)

**Function:** To filter a sound speed profile by eliminating points from it while still leaving a good representation of the curve.

**Where Called:** Main program

**Parameter Input:**

- D - An array containing the profile depths in meters.
- S - An array containing the profile sound speeds in meters/sec.
- N - The number of points in the profile.
- NSEL - The maximum number of points that remain in the profile after the elimination process.
- ER - The tolerance limit in meters/sec. used in the elimination process.

**COMMON Input:** None

**Card Input:** None

**File Input:** None

**Parameter Output:**

- SR - An array containing the sound speeds in meters/sec. for the filtered profile. Points that have been eliminated from the original array (S) are replaced by zeros in the SR array.
- NR - The number of non-zero points in the filtered profile.

**COMMON Output:** None

**Printer Output:** None

**File Output:** None


**Description:** The subroutine first checks to see that all the sound speeds are within an acceptable range (1410.0 - 1720.0 m/s). Those that are outside the range are discarded. If there are less than 3 points left, the filtering is not done.

The filtering process goes as follows: A line is drawn from the first to the third point in the profile, skipping the second point. Knowing the depth of the second we can find where the second point is on this line and thus know the sound speed at that point. We then compare this calculated sound speed with the observed sound speed. If they are within a certain tolerance, then a line is drawn from point 1 to point 4. The second and third points are then checked to see if they fall within the tolerance. If they do, then a line is drawn from point 1 to point 5 and so on until a preceding point does not fall within the tolerance.

When a point does fall outside the tolerance, the line is then drawn from the first point to the last point before the tolerance was exceeded and all of the preceding points (except the first) are eliminated. The endpoint of the line segment is then taken as the first point. A line is drawn to the third point after the end point and the process is repeated.

Certain points are left in the filtered profile, no matter whether they fall in the tolerance or not. These points are the first and last points in the profile and the point with the minimum sound speed.


Error  
Messages:     None





FRITZ

Page 1 of 5










FRITZ

Page 4 of 5



FRITZ  
Page 5 of 5

#### IV.6 Subroutine LEGEND

**Function:** To put explanatory legends at the beginning of a set of RSVP profile plots.

**Where Called:** Main program

**Parameter Input:** None

**COMMON Input:** None

**Card Input:** None

**File Input:** None

**Parameter Outputs:** None

**COMMON Output:** None

**Printer Output:** None

**Plotter Output:** a) A legend containing an explanation of the numbers used to annotate each profile as follows:

- 1 - MODEL
- 2 - MEAN
- 3 - MINIMUM
- 4 - MAXIMUM
- 5 - MEAN - STANDARD DEVIATION
- 6 - MEAN + STANDARD DEVIATION
- 7 - REPRESENTATIVE 1
- 8 - REPRESENTATIVE 2
- 9 - REPRESENTATIVE 3


b) A legend containing an explanation of the codes used on the annotation at the bottom of the graph to describe the processing done on each profile:

- M - EXTENDED WITH MEAN
- T - EXTENDED WITH MEAN AND ARCHIVAL
- F - FILTERED
- E - EDITED

**File Output:** None

**Description:** The two legends described under Plotter Output are drawn one above the other.

**Error**  
**Message:** None



LEGEND

Page 1 of 1

#### IV.7 Subroutine PAGE (IPG, X, ISET, LBX)

**Function:** To store an RSVP profile for printing, and later to print it.

**Where Called:** Main program

**Parameter Input:**

- IPG** - An indicator that is set by the calling program to 0 when a sound speed profile is to be stored in an internal print array, and to 1 when the sound speed profiles previously accumulated in the print array are to be printed.
- X** - An array containing sound speeds in meters/sec. to be stored in the print array.
- ISET** - The RSVP request number corresponding to the array.
- LBX** - An alphanumeric label identifying the kind of processing that has been done on the profile (e.g. extension, filtering).

**COMMON Input:** None

**Card Input:** None

**File Input:** None

**Parameter Output:** None

**COMMON Output:** None


**Printer Output:** A page containing up to 12 sound speed profiles.

**File Output:** None

**Description:** Each time that subroutine PAGE is called, the profile in array X is transferred to an internal array PRL. An internal print column counter, ICOL, is incremented by 1 for each array stored. When the number of columns reaches 12, or when the parameter IPG is set to 1, a page of sound speed profiles is printed, one profile per column, with the request sequence number (ISET), and the identifying label (LBX) at the top of each column.

**Error Messages:** None





PAGE

Page 1 of 1

#### IV.8 Subroutine PLDASH (X1, Y1, X2, Y2)

**Function:** To plot a dashed straight line from one point to another.

**Parameter Input:**

X1	- The X-coordinate in inches of the beginning point.
Y1	- The Y-coordinate in inches of the beginning point.
X2	- The X-coordinate in inches of the ending point.
Y2	- The Y-coordinate in inches of the ending point.

**COMMON Input:** None

**Card Input:** None

**File Input:** None

**Parameter Output:** None


**COMMON Output:** None

**Printer Output:** None

**Plotter Output:** A line of dashes between (X1, Y1) and (X2, Y2).

**File Output:** None

**Description:** The length of a dash and the spacing between dashes are constants in the program. The number of dashes and the X and Y distances between dashes are calculated using these constants. Then the dashed line is drawn.



PLDASH

Page 1 of 1

#### IV.9 Subroutine PLDOT (X1, Y1, X2, Y2)

**Function:** To plot a dotted straight line from one point to another.

**Parameter Input:**

X1	- The X-coordinate in inches of the beginning point.
Y1	- The Y-coordinate in inches of the beginning point.
X2	- The X-coordinate in inches of the ending point.
Y2	- The Y-coordinate in inches of the ending point.

**COMMON Input:** None

**Card Input:** None

**File Input:** None

**Parameter Output:** None


**COMMON Output:** None

**Printer Output:** None

**Plotter Output:** A line of dots between (X1, Y1) and (X2, Y2).

**File Output:** None

**Description:** The distance between dots is a constant in the program. Using this constant, the number of dots and the X and Y distances between dots are calculated. Then the dotted line is drawn.



PLDOT

Page 1 of 1

#### IV.10 Subroutine PLOTIT (D, SS, ICN, ICAP1, ICAP2, LABEL, LOPT, DMAX)

**Function:** To plot a set of RSVP sound speed profiles on one graph.

**Where Called:** Main program

**Parameter Input:**

- D** - An array containing the profile depths in meters. These depths are the same for all profiles.
- SS** - An array containing sound speeds in meters/sec. for all profiles. A zero value indicates that there is no sound speed data at that point.
- ICN** - The number of sound speed profiles stored in array SS. Maximum value is 10.
- ICAP1** - A 40-character alphanumeric identifier for the RSVP run that selected the profiles according to location and month of the year.
- ICAP2** - A 30-character alphanumeric identifier from the RSVPPLP card input.
- LABEL** - An array containing up to 5 descriptors for each profile plotted. Word 1 contains the profile index number (1-9) used to annotate each individual profile. Words 2-5 contain the codes (M, T, F, E) used to indicate the processing that has been done on the profile. See Section IV.6 (Subroutine LEGEND) for an explanation of the profile index numbers and the processing codes.
- LOPT** - A user-specified plot option indicator. If LOPT is set to P, the profile is not annotated. If LOPT is set to N, the profile is annotated at every 5th point with the profile index number.
- DMAX** - The user-specified maximum depth in meters for plotting. If DMAX is set to 0, a default of 6000 meters is assumed. If DMAX is set negative, the maximum depth is determined from the data in the D array.

**Card Input:** None

**File Input:** None

**Parameter Output:**

- DMAX** - The maximum depth in meters for plotting.

**COMMON  
Output:**

Subroutine PLOTIT sets up COMMON storage tables that are used by its subsidiary subroutines ANNOT, AXES, LEGEND, PLPROF, and SCALDS to choose scaling factors for the plotting of depth and sound speed. There is one labelled COMMON block for depth, and another for sound speed.

Depth Scaling

/DPLOT/. NOX - Number of available depth scales. Currently set to 6.

ISCALD - Index into the depth scaling arrays used for the current graph.

The following arrays contain NOX entries, one for each depth scale:

LENY - Number of divisions on the depth axis.

YINC - Length in inches of a division on the depth axis.

DPINC - Length in meters represented by a division on the depth axis.

DPMAX - Maximum depth in meters on the depth axis.

YFAC - Multiplicative factor to convert axis tic annotation to meters.

The values in these arrays are set as follows:

Array Index	LENY	YINC	DPINC	DPMAX	YFAC
1	6	1.4	40.	240.	1.
2	6	1.4	100.	600.	100.
3	6	1.4	200.	1200.	100.
4	6	1.4	500.	3000.	100.
5	6	1.4	1000.	6000.	1000.
6	6	1.4	2000.	12000.	1000.

### Sound speed scaling

/SPLOT/ NOY - Number of available sound speed scales.  
Currently set to 6.

ISCALS - Index into the sound speed scaling arrays  
used for the current graph.

The following arrays contain NOY entries, one for each sound  
speed scale:

LENX - Number of divisions on the sound speed  
axis.

XINC - Length in inches of a division on the sound  
speed axis.

SSINC - Length in meters/sec. represented by a  
division on the sound speed axis.

SSMIN - Minimum sound speed in meters/sec. on  
the sound speed axis.

SSMAX - Maximum sound speed in meters/sec. on  
the sound speed axis.

The values in these arrays are set as follows:

Array Index	LENX	XINC	SSINC	SSMIN	SSMAX
1	6	1.0	20.	1440.	1560.
2	6	1.0	20.	1480.	1600.
3	6	1.0	40.	1400.	1640.
4	6	1.0	40.	1440.	1680.
5	6	1.0	40.	1480.	1720.
6	6	1.0	100.	1200.	1800.

Printer  
Output: None


Plotter  
Output: Output from PLOTIT is one graph of sound speed profiles. The  
axes are annotated, and identifying titles are drawn. More than  
one sound speed profile may be drawn on the graph. Each profile  
may be annotated.

File Output: None



**Description:** Subroutine PLOTIT calls subroutine SCALDS to determine the scaling to be used for plotting depth and sound speed. It then calls subroutine AXES to draw and annotate the axes for the graph, subroutine PLPROF to plot the profiles, and subroutine ANNOT to draw captions at the bottom of the graph.

**Error  
Messages:** None



PLOTIT

Page 1 of 1

#### IV.11 Subroutine PLPROF (D, S, LABP, LOPT)

**Function:** To plot an RSVP sound speed profile.

**Where Called:** Subroutine PLOTIT.

**Parameter Input:**

- D - An array containing profile depths in meters.
- S - An array containing sound speeds in meters/sec. A zero value indicates that there is no sound speed data at that point.
- LABP - A profile index number used for annotation on the profile plot. See subroutine LEGEND for a description of this index number.
- LOPT - A user-specified plot option indicator. If LOPT is set to P, the profile is not annotated. If LOPT is set to N, the profile is annotated with the profile index number (LABP) at every 5th point.

**COMMON Input:**

- /DPLOT/ ISCALD - Index into the depth scaling arrays used for the current graph.
- YINC - Length in inches of a division on the depth axis.
- DPINC - Length in meters represented by a division on the depth axis.
- DPMAX - Maximum depth in meters on the depth axis.
- /SPLOT/ ISCALs - Index into the sound speed scaling arrays used for the current graph.
- XINC - Length in inches of a division on the sound speed axis.
- SSINC - Length in meters/sec. represented by a division on the sound speed axis.
- SSMIN - Minimum sound speed in meters/sec. on the sound speed axis.
- SSMAX - Maximum sound speed in meters/sec. on the sound speed axis.

Card Input: None

File Input: None

Parameter Output: None

COMMON Output: None


Printer Output: Error Message. See below for details.

File Output: None

Plotter Output: Subroutine PLPROF plots one profile. If LOPT is set to N, a plot annotated at every 5th point with the profile index number (LABP) is produced. If LOPT is set to P, a plot is produced with no annotation.


Description: The profile points that have zero sound speed or depths deeper than the maximum depth for plotting are eliminated from the profile. Then, using the scaling indicated by the values in ISCALD and ISCALs, the profile is plotted, either annotated or not, depending on the setting of LOPT.

Error Messages: The subroutine checks that the sound speeds to be plotted are within the specified minimum and maximum sound speed values. If any are not, an error message is printed, and processing continues. See Section III.1.2 for a detailed description of the error messages.




PLPROF

Page 1 of 3



PLPROF

Page 2 of 3



PLPROF

Page 3 of 3

#### IV.12 Subroutine PNCH (D, S, ICAP1, ICAP2, ICAP3)

**Function:** To write a sound speed profile to a disk file in card image form for punching.

**Where Called:** Main program.

**Parameter Input:**

- D - Array containing profile depths in meters.
- S - Array containing profile sound speeds in meters/sec.
- ICAP1 - A 40-character alphanumeric identifier, from the original RSVP request. Written in columns 1-40 of the first card image for the profile.
- ICAP2 - A 30-character alphanumeric identifier, from the input parameter card. Written in columns 41-70 of the first card image for the profile.
- ICAP3 - 10 alphanumeric characters identifying the profile type and the processing done on it. Written in columns 71-80 of the first card image for the profile.

**COMMON Input:** None

**Card Input:** None

**File Input:** None

**Parameter Output:** None

**COMMON Output:** None


**Printer Output:** None

**File Output:** On logical unit 3, card images of the sound speed profile. See Section III-3 for a description of the file.

**Description:** A header card containing identifiers for the profile is written, followed by a card containing the number of points in the profile. Then the profiles are written out, 4 points per card image.

**Error Messages:** None





PNCH

Page 1 of 1

#### IV.13 Subroutine SCALDS (D, SS, ICN, DMAX)

**Function:** To determine the scaling for depths and sound speeds on a multi-profile plot.

**Where Called:** Subroutine PLOTIT

**Parameter Input:**

- D - An array containing profile depths in meters. These depths are the same for all profiles.
- SS - An array containing sound speeds in meters/sec. for all profiles. A zero value indicates that there is no sound speed data at that point.
- ICN - The number of sound speed profiles stored in array SS. Maximum value is 10.
- DMAX - The user-specified maximum depth in meters for plotting. If DMAX is set to zero, a default of 6000 meters is assumed. If DMAX is set negative, the maximum depth is determined from the data in the D array.

**COMMON Input:**

- /DPLOT/ NOX - Number of available depth scales.
- DPMAX - Array of maximum depths in meters, one for each depth scale.
- /SPLOT/ NOY - Number of available sound speed scales.
- SSMIN - Array of minimum sound speeds in meters/sec., one for each sound speed scale.
- SSMAX - Array of maximum sound speeds in meters/sec., one for each sound speed scale.

**Card Input:** None

**File Input:** None

**Parameter Output:**

- DMAX - Maximum depth in meters for plotting.

**COMMON Output:**

- /DPLOT/ ISCALD - An index into the tables used for scaling the depth for plotting.
- /SPLOT/ ISCALs - An index into the tables used for scaling the sound speed for plotting.

**Printer Output:** None

**File Output:** None

AD-A109 855

OCEAN DATA SYSTEMS INC ROCKVILLE MD  
RSVP UPGRADE AND MAINTENANCE.(U)  
DEC 81 J WEBSTER

F/G 20/1


UNCLASSIFIED

N00014-78-C-0818  
NL

2 OF 2

AD-A  
(U) (S) (C) (R) (E) (N) (T) (I) (O) (N) (L) (Y) (I) (N) (G) (S) (I) (N) (C) (R) (O) (C) (K) (V) (I) (L) (L) (E) (M) (D) (R) (S) (V) (P) (U) (P) (G) (R) (A) (D) (E) (A) (N) (D) (M) (A) (I) (N) (T) (E) (N) (A) (N) (C) (E) (U) (D) (E) (C) (8) (1) (J) (W) (E) (B) (S) (T) (E) (R)


END  
DATE  
FILMED  
02-82  
DTIC



**Description:** The subroutine searches through the multi-profile array to find minimum and maximum sound speeds over all the profiles. It then searches through the tables of sound speed minima and maxima until it finds a set between which these computed minimum and maximum will fit. If a fit cannot be found, the broadest scale available is selected.


The subroutine finds the deepest depth at which sound speed data exist in the multi-profile array. If DMAX has been specified as a negative value, then DMAX is reset to this maximum value. If DMAX has been specified as zero, then DMAX is reset to 6000. Otherwise, DMAX is left as originally specified. The value of DMAX is then used to search through the tables of depth maxima to find a value which will fit the value of DMAX. If none is found, then the deepest maximum available is used.

**Error  
Messages:** None



SCALDS

Page 1 of 2



SCALDS

Page 2 of 2

# **V. CROSS REFERENCE CHARTS**

## **V.1 Subroutine Cross Reference**

Subroutine Called Calling Program	ABRT	ANNOT	AXES	FRITZ	LEGEND	PAGE	PLDASH	PLDOT	PLOTIT	PLPROF	PNCH	SCALDS
MAIN PROGRAM	X			X	X	X			X		X	
ABRT												
ANNOT												
AXES												
FRITZ												
LEGEND												
PAGE												
PLDASH												
PLDOT												
PLOTIT		X	X						X			X
PLPROF							X	X				
PNCH												
SCALDS												



## V.2 COMMON Cross Reference

PROGRAM		MAIN	ABRT	ANNO	AXES	FRITZ	LEGEND	PAGE	PLDASH	PLDOT	PLOTT	PLPROF	PNCH	SCALDS
Block	Variable													
DPLOT	DPINC				R						D	R		
	DPMAX				R						D	R		R
	ISCALD				R							R		D
	LENY				R						D	R		
	NOX										D	R		R
	YFAC				R						D			
	YINC				R						D	R		
SPLOT	ISCALS				R							R		D
	LENX				R						D			
	NOY										D			R
	SSINC				R						D	R		
	SSMAX										D	R		R
	SSMIN				R						D	R		R
	XINC				R						D	R		

R — The indicated program refers to the specified COMMON variable.

D — The specified COMMON variable is defined in the indicated program.

## **VI. USER'S GUIDE**

### **VI.1 File Identification**

The FORTRAN source and the binary code for RSVPLP are stored at DTNSRDC and at Eglin. The file names are the same at both places. The file identifiers is shown below.

<b>FORTRAN Source (Program Library)</b>	<b>Binary Code</b>	<b>ID at Eglin</b>	<b>SN at Eglin</b>	<b>ID at NSRDC</b>
<b>PVEHRSVPLOT PUNCHPL</b>	<b>PVEHRSVPLOT PUNCHLGO</b>	<b>KM</b>	<b>USET1</b>	<b>PVEH</b>

Sample job streams for executing RSVPLP at Eglin and DTNSRDC are presented on the following pages.

- ```
X107.T375.P4.  
COMMENT.  
COMMENT.  
COMMENT.  
COMMENT.  
COMMENT.  
ATTACH,LGO,PVEHRSVPPLUTPUNCHLGO,ID=KM,SN=USET1,MH=1.  
ATTACH,TAPE1,RSVPOUT,ID=KM,SN=USET1,MR=1.  
ATTACH,PLOT,ZETAPLOT.ID=MZ,SN=USET2,MH=1.  
REQUEST,PLTCDS,*Q.  
REQUEST,TAPE3,*Q.  
LOAD,PLOT.  
LGO.  
ROUTE,TAPE3,DC=PU,TIU=AD.  
ROUTE,PLTCDS,DC=PU,TID=AD,EC=80COL.  
00000000000000000000000000 ← 7/6/9 card  
041TFCP  
047TFCP  
048TFCP  
049TFCP  
00000000000000000000000000 ← 6/7/8/9 card
```
- MASHIMOTO 1608 921HVT16M2C 26
- RUN RSVPLP AT EGLIN TO  
MAKE A /EIA PLOT AND IO  
PUNCH SOUND SPEED PROFILES.
- MODEL  
REP1  
REW?  
NEP3

- X107.T375.P4.  
COMMENT.  
COMMENT.  
COMMENT.  
COMMENT.  
ATTACH=LGO,PVENRSVPLOT,PUNCH,LGO,ID=KM,SN=USET1,MR=1.  
ATTACH=TAPE1,RSVPOUT,ID=KM,SN=USET1,MH=1.  
REQUEST,TAPE3,00.  
LGO.  
ROUTE,TAPE3,DC=PU,TID=AD.  
000000000000000000000000 ← 7/8/9 card  
041TFC  
047TFC  
048TFC  
049TFC  
000000000000000000000000 ← 6/7/8/9 card
- MASHIMOTO 100A 021MVT16M2C 26  
RUN RSVPLP AT EGLIN TO PUNCH  
SOUND SPEED PROFILES.  
MODEL  
REP1  
HEP2  
HEP3

- Run at Eglin to produce a deferred plotting file to preview on the Tektronix.

X107.T375.P4.

MASHIMOTO

100R 0210V116M2C

26

COMMENT.

RUN RSVPLP AT EGLIN TO GET A  
DEFERRED PLOTTING FILE FOR USE  
WITH THE TEKTRONIX PREVIEWER.

COMMENT.

COMMENT.

COMMENT.

COMMENT.

ATTACH.LGO,PVEHRSVPPLUTPUNCHLGO,ID=KM,SN=USET1,MR=1.

ATTACH.TAPE1,RSVPOUT,ID=KM,SN=USET1,MR=1.

REQUEST.PLTCD,PF,SN=USET1.

ATTACH.TEK,TEKPROCF,FILE,ID=KW,SN=USET2,MR=1.

BEGIN,MAKE,TEK,RSVPPLP.

CATALOG.PLTCD,RSVPLOTTEST,ID=KM.

000000000000000000000000 ← 7/8/9 card

041TFP

MODEL

047TFP

REP1

048TFP

REP2

049TFP

REP3

000000000000000000000000 ← 6/7/8/9 card

- Run at Carderock to produce a Calcomp plot and to punch sound speed profiles.

PUJAY,CM60000,T50,P4,MT1.

CHANGE,PUJA,IVBGT18919.

COMMENT.

RUN RSVPLP AT CARDEROCK  
TO PRODUCE CALCOMP PLOTS  
AND PUNCHED SOUND SPEED PROFILES.

COMMENT.

COMMENT.

COMMENT.

ATTACH.LGO,PVEHRSVPPLUTPUNCHLGO,ID=PVEH,MR=1.

ATTACH.TAPE1,RSVPOUT,ID=PVEH,MR=1.

LABEL.TAPE20,D=HY,R=RING,L=RSVPLOT,VSN=CK0837.

ROUTE.TAPE3,DC=PU,DEF,TID=C.

ATTACH.CALC936.

LIBRARY.CALC936.

LGO.

000000000000000000000000 ← 7/8/9 card

011TFCP

MODEL

02256CP

MEAN +- S. D.

03134CP

MODEL,MIN,MAX

047TFCP

REP1

048TFCP

REP2

057TFCP

REP1

058TFCP

REP2

000000000000000000000000 ← 6/7/8/9 card

**odsi OCEAN DATA SYSTEMS, INC.**  
6000 EXECUTIVE BLVD., ROCKVILLE, MARYLAND 20852 • 301/881-3031

MEMORANDUM

To: George Kerr, NORDA Code 321

From: Jacqueline Webster *fw*

Date: December 9, 1981

The Cyber Control Language (CCL) procedure for running RSVP has been modified as you requested. It is stored as cycle 4 of file RSVPPROC, ID=KT. A second procedure called GETDATA was added to the procedure file. The procedure for running RSVP (PRSV) invokes the GETDATA procedure.

You no longer need to specify the magnetic tape Volume Serial Number (VSN) on your BEGIN command when running the procedure. Instead, you can specify the ocean basin on the BEGIN command, and the procedure will automatically mount the appropriate tape. If there is a problem with the tape, the procedure will mount the backup tape. You can, however, still specify your own tape serial number on the BEGIN card, and this will override the automatic mount.

The order of the parameters on the BEGIN command has been changed slightly. The following is a description of the parameters for the procedure:

.PROC, PRSV, OCNBASN, STORFIL, TAPENUM,  
EXTRACT=NO, SAVE=NO, PLOT=NO, CARDS=NO, PROCFIL=#FILE

OCNBASN — Name of the ocean basin — ATLARC, CARIB, CENATL,  
CENPAC, INDIAN, MEDSEA, NORATL, NORPAC, PHIOKJP,  
or SATLPAC

STORFIL — Name of the permanent file on which the extracted RSVP  
data is to be stored. The ID will be KM. This parameter is  
used only when the parameter SAVE is set to YES.

TAPENUM — Volume Serial Number (VSN) of tape to be used as input to  
RSVP. This parameter is optional; when used, it overrides  
the automatic tape mount.

EXTRACT — Set to YES to extract RSVP data, set to NO otherwise.

SAVE — Set to YES to save the extracted RSVP data, set to NO  
otherwise.

**PLOT**      — Set to YES to plot the extracted RSVP data, set to NO otherwise.

**CARDS**     — Set to YES to select sound speed profiles from the extracted RSVP profiles, and to store these selected profiles as card images on disk in a format accepted by the Model Interface program.

Attached are a tabulation of the tape serial numbers and a listing of the CCL procedure.

RSVP Input Tapes

| Ocean Basin | Tape Label  | Original  |           | Backup    |           |
|-------------|-------------|-----------|-----------|-----------|-----------|
|             |             | Eglin VSN | NORDA VSN | Eglin VSN | NORDA VSN |
| ATLARC      | PUJAATLARC  | 5388      | 1346      | 11697     | 1307      |
| CARIB       | PUJACARIB   | 4050      | 1313      | 12100     | 1222      |
| CENATL      | PUJACENATL  | 0774      | 1499      | 0863      | 1495      |
| CENPAC      | PUJACENPAC  | 0462      | 1326      | 11020     | 1212      |
| INDIAN      | PUJAINDIAN  | 3799      | 1228      | 5150      | 1496      |
| MEDSEA      | PUJAMEDSEA  | 4036      | 1309      | 16848     | 1357      |
| NORATL      | PUJANORATL  | 0400      | 1493      | 6135      | 1287      |
| NORPAC      | PUJANORPAC  | 10575     | 1234      | 16386     | 1355      |
| PHIOKJP     | PUJAPHIOKJP | 10996     | 1213      | 12645     | 1501      |
| SATLPAC     | PUJASATLPAC | 15056     | 1368      | 16382     | 1334      |

```

.PROC, PRSUP, OCNBASN, STORFIL, TAPENUM=,
EXTRACT=NO, SAVE=NO, PLOT=NO, CARDS=NO, PROCFIL=$FILE.
.X
.X-----GET INPUT DATA FOR RSUP-----
.IF, $EXTRACT$.EQ.$YES$, JMPA.
REQUEST, TAPE60, XPF.
BEGIN, GETDATA, PROCFIL, OCNBASN, TAPENUM.
REWIND, DATIN.
ATTACH, TAPE4, PUEHDEEPSARCHIVAL, ID=KM, MR=1.
.X
ATTACH, BIN, PUEHRSUPLGO, ID=KM, MR=1.
LDSET, PRESET=ZERO.
LOAD, BIN.
EXECUTE, RSUP, DATIN.
.X
.IF, $SAVE$.EQ.$YES$, JMPB.
CATALOG, TAPE60, STORFIL, ID=KM.
REWIND, TAPE1, TAPE60.
COPY, TAPE60, TAPE1.
RETURN, TAPE60.
ENDIF, JMPB.
ENDIF, JMPA.
.X
.IF, $PLOTS$.EQ.$YES$.OR.$CARDS$.EQ.$YES$, JMPH.
.X-----RUN RSUPPLOT PUNCH PROGRAM-----
.IF, .NOT. FILE (TAPE1, AS), ATTAPE1.
ATTACH, TAPE1, STORFIL, ID=KM, MR=1.
ENDIF, ATTAPE1.
REWIND, TAPE1.
.X
ATTACH, LGO, PUEHRSUPLPLOT PUNCHLGO, ID=KM, MR=1.
REQUEST, PLTCDS, XQ.

```



```

REQUEST,TAPE3,XPF.
X
IF,SPLOTS.EQ.$YES$,JMPD.
ATTACH,DRAW,ZETAPLOTf185,ID=MZ,MR=1.
LOAD,DRAW.
LOAD,LGO.
NOGO,RSUPPLP.
ENDIF,JMPD.
X
IF,$CARDS$.EQ.$YES$ .AND. $PLOTS$.EQ.$NO$, JMPE.
LOAD,LGO.
NOGO,RSUPPLP.
ENDIF,JMPE.
X
RSUPPLP.
IF,$CARDS$.EQ.$YES$,JMPG.
CATALOG,TAPE3,PUNCH,ID=KM.
ENDIF,JMPG.
X
IF,SPLOTS.EQ.$YES$,JMPP.
ROUTE,PLTCDS,DC=PR,fID=AC,FC=U9.
ENDIF,JMPP.
X
REVERT.
X
XX
X
PROC,GETDATA,OCNBASN,TAPENUM=.
X-----GET INPUT DATA FOR RSUP-----
X IF RSUP INPUT FILE IS ALREADY
X ATTACHED, ASSUME THAT THE USER WANTS
X TO USE HIS OWN FILE.
X IF A TAPE NUMBER IS SPECIFIED BY THE

```

```

* USER, THEN THIS OVERRIDES THE REGULAR
* RSUP TAPE.
* OTHERWISE ATTACH THE APPROPRIATE TAPE
* FOR THE SPECIFIED OCEAN BASIN.
* IF THE TAPE IS BAD, THEN ATTACH THE
* BACKUP TAPE.
*-----CHECK FOR FILE INPUT
* IF, .NOT. FILE(DATIN,AS),GETFILE.
*-----NO FILE, SO GET TAPE
* RETURN, TAPE2.
*-----CHECK FOR USER-SPECIFIED TAPE.
* IF $TAPENUMS.NE.$$,GETOUN.
* LABEL, TAPE2,R,D=HD,L=PUJA_OCNBASN,USN=TAPENUM.
* COPYBF, TAPE2,DATIN.
* SKIP,GETTAPE.
* ENDIF,GETOUN.
*-----ATLARC
* IF, $OCNBASNS.EQ.$ATLARCS,DOATLARC.
* LABEL, TAPE2,R,D=HD,L=PUJA_OCNBASN,USN=1346.
* COPYBF, TAPE2,DATIN.
* SKIP,GETTAPE.
* EXIT.
* UNLOAD, TAPE2.
* LABEL, TAPE2,R,D=HD,L=PUJA_OCNBASN,USN=1307.
* COPYBF, TAPE2,DATIN.
* SKIP,GETTAPE.
* ENDIF,DOATLARC.
*-----CARIB
* IF, $OCNBASNS.EQ.$CARIBS,DOCARIB.
* LABEL, TAPE2,R,D=HD,L=PUJA_OCNBASN,USN=1313.
* COPYBF, TAPE2,DATIN.
* SKIP,GETTAPE.
* EXIT.

```

UNLOAD TAPE2:  
LABEL TAPE2, R, D=HD, L=PUJA\_OCNBASN, USN=1222.  
COPYBF TAPE2, DATIN.  
SKIP GETTAPE:  
ENDIF, DOCARIB.  
\*-----CENATL

IF, SOCNBASNS.EQ.\$CENATLS, DOCENATL.  
LABEL TAPE2, R, D=HD, L=PUJA\_OCNBASN, USN=1499.  
COPYBF TAPE2, DATIN.  
SKIP GETTAPE:  
EXIT.

UNLOAD TAPE2:  
LABEL TAPE2, R, D=HD, L=PUJA\_OCNBASN, USN=1495.  
COPYBF TAPE2, DATIN.  
SKIP GETTAPE:  
ENDIF, DOCENATL.  
\*-----CENPAC

IF, SOCNBASNS.EQ.\$CENPACS, DOCENPAC.  
LABEL TAPE2, R, D=HD, L=PUJA\_OCNBASN, USN=1326.  
COPYBF TAPE2, DATIN.  
SKIP GETTAPE:  
EXIT.

UNLOAD TAPE2:  
LABEL TAPE2, R, D=HD, L=PUJA\_OCNBASN, USN=1212.  
COPYBF TAPE2, DATIN.  
SKIP GETTAPE:  
ENDIF, DOCENPAC.  
\*-----INDIAN

IF, SOCNBASNS.EQ.\$INDIANS, DOINDIAN.  
LABEL TAPE2, R, D=HD, L=PUJA\_OCNBASN, USN=1228.  
COPYBF TAPE2, DATIN.  
SKIP GETTAPE:  
EXIT.

```

UNLOAD TAPE2;
LABEL TAPE2, R, D=HD, L=PUJA_OCNBASN, USN=1496.
COPYBF TAPE2, DATIN.
SKIP GETTAPE.
ENDIF, DOINDIAN.
*-----MEDSEA
IF, SOCNBASNS.EQ.$MEDSEAS, DOMEDSEA.
LABEL TAPE2, R, D=HD, L=PUJA_OCNBASN, USN=1309.
COPYBF TAPE2, DATIN.
SKIP, GETTAPE.
EXIT.
UNLOAD TAPE2;
LABEL TAPE2, R, D=HD, L=PUJA_OCNBASN, USN=1357.
COPYBF TAPE2, DATIN.
SKIP, GETTAPE.
ENDIF, DOMEDSEA.
*-----NORATL
IF, SOCNBASNS.EQ.$NORATLS, DONORATL.
LABEL TAPE2, R, D=HD, L=PUJA_OCNBASN, USN=1493.
COPYBF TAPE2, DATIN.
SKIP, GETTAPE.
EXIT.
UNLOAD TAPE2;
LABEL TAPE2, R, D=HD, L=PUJA_OCNBASN, USN=1287.
COPYBF TAPE2, DATIN.
SKIP, GETTAPE.
ENDIF, DONORATL.
*-----NORPAC
IF, SOCNBASNS.EQ.$NORPACS, DONORPAC.
LABEL TAPE2, R, D=HD, L=PUJA_OCNBASN, USN=1234.
COPYBF TAPE2, DATIN.
SKIP, GETTAPE.
EXIT.

```

```

UNLOAD, TAPE2;
LABEL, TAPE2, R, D=HD, L=PUJA_OCNBASN, USN=1355.
COPYBF, TAPE2, DATIN.
SKIP, GETTAPE.
ENDIF, DONORPAC.
.X-----PHIOKJP
IFE, SOCNBASNS.EQ.SPHIOKJPS, DOPHIOKJP.
LABEL, TAPE2, R, D=HD, L=PUJA_OCNBASN, USN=1213.
COPYBF, TAPE2, DATIN.
SKIP, GETTAPE.
EXIT.
UNLOAD, TAPE2;
LABEL, TAPE2, R, D=HD, L=PUJA_OCNBASN, USN=1501.
COPYBF, TAPE2, DATIN.
SKIP, GETTAPE.
ENDIF, DOPHIOKJP.
.X-----SATLPAC
IFE, SOCNBASNS.EQ.SSATLPACS, DOSATLPAC.
LABEL, TAPE2, R, D=HD, L=PUJA_OCNBASN, USN=1368.
COPYBF, TAPE2, DATIN.
SKIP, GETTAPE.
EXIT.
UNLOAD, TAPE2;
LABEL, TAPE2, R, D=HD, L=PUJA_OCNBASN, USN=1334.
COPYBF, TAPE2, DATIN.
SKIP, GETTAPE.
ENDIF, DOSATLPAC.
.X-----
COMMENT. ***** ERROR
COMMENT. *****
COMMENT. SPECIFIED OCEAN BASIN IS NOT AVAILABLE.
COMMENT. CHECK YOUR BEGIN CARD.

```

REVERT, ABORT.

.X

.X

.X

ENDIF, GETTAPE.

UNLOAD, TAPE2.

.X

ENDIF, GETFILE.

.X

REVERT.

ND  
DATE